

DuraPack[®] Python[®]

HIGH-PERFORMANCE AUTOMATED SIDE LOADER

OPERATION MANUAL ISSUED SEPTEMBER 2017

Failure to follow all instructions and safety precautions in this manual, in the Service Manual, in other manufacturers' manuals and on the safety decals attached to the product could result in serious injury or death to operators or bystanders and/ or damage to property.

DO NOT operate this vehicle before you READ and UNDERSTAND this Operation Manual, the Service Manual for this unit, other applicable manufacturers' manuals, and the safety decals on the product.

Each operator of this unit must read and understand all directions in this manual before they first operate this vehicle.

Keep this manual in the cab for new operators and to remind all operators about safe use.





READ THIS MANUAL!

EVERY PERSON who will **OPERATE**, **MAINTAIN, REPAIR, OR OTHERWISE WORK** with the Heil unit **MUST READ AND UNDERSTAND** this entire Operator's Manual before starting the engine or activating any switches or controls. **MAKE SURE** to read the Service Manual for the unit **BEFORE** you do any maintenance or repair procedures.

ALL USERS of this equipment must be trained professionals who understand how the machine operates and know how to avoid the risks associated with driving the vehicle and with picking up, compacting, and dumping refuse in an ever-changing traffic environment.

If you do not understand an operation or instruction, seek additional help or instruction from a qualified source **BEFORE** you operate the unit.

Introduction

Section Preview	4
How to Use This Manual	5
To the Owner	6
To the Operator	7
To the Operator (Continued)	8
To the Mechanic (Continued)	9
Warranty Claims and Inquiries	
Customer Service and Repair Parts Contact Information	11
Models	
Serial Plate Locations	13
Reading the Serial Plate	14
Product Nomenclature	
Product Nomenclature (Continued)	
Lift Nomenclature	21
Glossary	
Safety Messages and Decals	
Section Preview	
Precautionary Statements	
General Safety Precautions	
General Safety Precautions (Continued)	29
Decals	
Dump/Service Hoist Decal Placement	
Eject Decal Placement	
Decal Images	42
Care of Decals	51
Lock-Out/Tag-Out Procedure	
Section Preview	
Issued September 2017	Convright 2017 Heil Environmental

Locking Out the Unit	57
Features, Controls, Switches, and Indicator Lights	
Section Preview	60
Features	61
Unit Interlocks	62
Operation Specifications	63
Operation Specifications (Continued)	64
In-Cab Main Control Panel	65
In-Cab Main Control Panel (Continued)	66
In-Cab Main Control Panel (Continued)	67
Python Lift Joystick Controls	68
Python Lift Joystick Controls (Continued)	69
Python Lift Joystick Controls (Continued)	70
Service Hoist	71
Daily Checklist	
Body Daily Checklist	74
Refuse Vehicle Daily Inspection	76
Daily Checks and Inspections	77
Body and Tailgate Props	
Section Preview	86
Propping the Body of a Service Hoist Unit	87
Propping the Body of a Service Hoist Unit (Continued)	
Propping the Body of a Service Hoist Unit (Continued)	89
Propping the Body of a Service Lift (Serviceable Eject) Unit	90
Propping the Body of a Service Lift Unit (Continued)	91
Propping the Body of a Service Lift Unit (Continued)	92
Propping the Tailgate	93
Propping the Tailgate (Continued)	94

Before Going on Route

Section Preview	96
Battery Disconnect Switch / Daily Checklist	97
Before Starting a Route / Cold Weather Warmup Procedure	98
Preparing the Unit to Check the Hydraulic Oil Level	99
Hydraulic Oil Tank with Sight Gauge	100
Check the Traveling or "In-transit" Position	101

On-Route Operation Procedures

Section Preview	104
Driving to Pick-up Locations	105
Lifting and Loading Refuse with the Python Lift Arm	106
Lifting and Loading Refuse with the Python Lift Arm (Continued)	107
Lifting and Loading Refuse with the Python Lift Arm (Continued)	108
Lifting and Loading Refuse with the Python Lift Arm (Continued)	109
Compacting the Load	110
_eaving the Route for the Landfill/Transfer Station (Continued)	111

Landfill/Transfer Station/Recycle Center Procedures

Section Preview	114
Setting up an Eject Unit for Unloading	115
Unloading an Eject Unit	116
Unloading an Eject Unit (Continued)	117
Unloading an Eject Unit (Continued)	118
Setting up a Dump Unit for Unloading	119
Unloading a Dump Unit	120
Unloading a Dump Unit (Continued)	121
Unloading a Dump Unit (Continued)	122
Unloading a Dump Unit (Continued)	123
Unloading a Dump Unit (Continued)	124

Cortex Controller™

Section Preview	
Cortex Controller Controls Troubleshooting	127
Hydraulic Pump Shutdown (Continued)	
Diagnostic Fault Codes	129
End of Day Procedures	
Section Preview	
End of Days Procedures	133
Preventive Maintenance Chart	
Body Preventive Maintenance Chart	136
Lubrication Guide	
Body Lubrication Guide	140
Body Lubrication Guide (Continued)	141
Lift Lubrication Guide	142
Compressed Natural Gas (CNG) Option	
Important Safety Information	144
Important Safety Information (Continued)	145
Important Safety Information (Continued)	146
Compressed Natural Gas (CNG) Fuel Module	147
Compressed Natural Gas (CNG) Fuel Module (Continued)	148
Compressed Natural Gas (CNG) Fuel Module (Continued)	149
CNG Vehicle Operator Emergency Response	150
CNG Vehicle Operator Emergency Response (Continued)	
CNG Front of Body / Top of Body Decal Placement	152
CNrG™ Tailgate Decal Placement	153
CNrG™ Tailgate Decal Images	154
CNrG™ Tailgate Decal Images	155

CNrG™ Tailgate Decal Images1	56
Starting Vehicle / Fueling Procedure1	157
Fueling Procedure (Continued)1	58
Fueling Procedure (Continued)1	59
Fueling Procedure (Continued) / Transfer Fueling (Defueling) Modes, Components and Procedures	60
Transfer Fueling (Defueling) Modes, Components and Procedures (Continued)1	61
Transfer Fueling (Defueling) Modes, Components and Procedures (Continued)1	62
Transfer Fueling (Defueling) Modes, Components and Procedures (Continued)1	63
Transfer Fueling (Defueling) Modes, Components and Procedures (Continued)1	64
CNG System Maintenance1	165
Inspection/Preventive Care Schedule / Preparation Before Maintenance	66
Fuel Management Module Reference Drawing1	67
Daily CNrG™ Fuel System Inspection1	68
Heil CNrG™ Solenoid System Option1	169
Heil CNrG™ Solenoid System Option (Continued)1	70
Heil CNrG™ Solenoid System Option (Continued)1	71
Heil CNrG™ Solenoid System Option (Continued)1	72
Heil CNrG™ Solenoid System Option (Continued)1	73
Heil CNrG™ Solenoid System Option (Continued)1	74
Heil CNrG™ Solenoid System Option (Continued)1	75
Heil CNrG™ Solenoid System Option (Continued)1	76
Heil CNrG™ Solenoid System Option (Continued)1	77
Heil CNrG™ Solenoid System Option (Continued)1	78
Index1	79

NOTES:

DuraPack[®] Python[®]

HIGH-PERFORMANCE AUTOMATED SIDE LOADER

OPERATION MANUAL ISSUED SEPTEMBER 2017 TP1DPPY-OM-0917

Copyright 2017, Heil Environmental Printed in U.S.A.

NOTES:

SECTION 1 INTRODUCTION

Copyright 2017, Heil Environmental Printed in U.S.A.

PREVIEW

Read this section to learn about:

- The responsibilities of the owner, the operator, and the mechanic
- Warranty information
- Telephone numbers and website URL for parts, technical support, warranty claims, training and manuals
- Identifying the different models
- Identifying the left (street side) of the unit
- The body and lift serial plates
- Various parts of the unit

HOW TO USE THIS MANUAL

Product Variance

This manual may cover options not included on your unit. Also, the location and appearance of the controls on your unit may be different than those shown in this manual. Make sure you know the location of the controls and how you operate the controls on your unit before operation.

Manual Sections

This manual is divided into thirteen (13) sections.

- 1. Introduction
- 2. Safety Messages and Decals
- 3. Lock-Out/Tag-Out Procedures
- 4. Features, Controls, Switches, and Indicator Lights
- 5. Body and Tailgate Props
- 6. Daily Checklist
- 7. Before Going on Route
- 8. On-Route Operation Procedures
- 9. Landfill/Transfer Station/Recycle Center Procedures
- 10.End of Day Procedures
- 11.Cortex Controller™
- 12. Preventive Maintenance Chart
- 13.Lubrication Guide

Terminology

This manual uses terminology that is defined in the **Glossary** which is in Section 1, Introduction.

Directives

When we give directions for using the equipment, we capitalize key words. These words are usually a command followed by a result.

For example, "MOVE the body raise switch to LOWER ...".

Use of Bold and CAPITAL Letters

We also put some words in **BOLD AND CAPS** for emphasis, usually related to safety or something of other importance, such as "**MAKE SURE** you close the side doors".

We put some words in just bold for emphasis, such as "All warranty repairs **must** be performed by ...".

Each DANGER, WARNING, and CAUTION notice precedes its applicable text.

TO THE OWNER

This manual is designed to help ensure safe, efficient and proper operation of The Heil Co. d/b/a Heil Environmental ("Heil") DuraPack[®] Python[®] Automated Side Loader (ASL) refuse collection vehicle (or the unit).

The manual will familiarize you with the unit and will give you proper operating procedures and tips.

For chassis operation and maintenance instructions, see the Chassis Owner's Manual and the DuraPack[®] Python[®] Service Manual.

As the owner, you have several responsibilities:

- You must complete and return the warranty registration for the unit to Heil.
- You must make sure that each operator has the proper driver's license.
- You must make sure that the operator does not operate the unit under the influence of drugs or alcohol.
- You must make sure that the unit is properly maintained to meet all local, state and federal requirements.
- You must keep the vehicle maintained and properly adjusted to meet the manufacturer's standards and recommendations.
- You must keep accurate records of daily inspections, breakdowns, malfunctions, maintenance and repairs of the unit.

- You must make sure that repairs are made that may affect the safe operation of the unit before it is made available for operation.
- You must provide adequate lighting on the unit for safe operation under low light or night conditions.
- You must provide adequate training for each operator and mechanic that will operate the unit BEFORE an operator goes on route or BEFORE a mechanic performs maintenance or repair procedures.
- You must determine if an operator or mechanic has difficulties reading or understanding this manual. When a person has difficulties reading or understanding this manual, you must provide adequate assistance so that the person does understand the material in this manual.
- You must make sure that each operator uses the equipment on a route as given in the instructions of this manual and other manufacturers' manuals.
- You must provide on-going training for each operator and mechanic that operates the unit.
- You must make sure that this manual stays with the vehicle at all times.

Properly operated and maintained, your DuraPack[®] Python[®] unit should give you years of low-cost, trouble free service.

TO THE OPERATOR

A DANGER

Do not operate the unit or perform repair or maintenance procedures on the unit until you read and understand all of the instructions in this manual. Failure to do so may result in injury or death to operators or bystanders.

NOTICE

For Compressed Natural Gas (CNG) units, this Operation Manual should be used in conjunction with any associated CNG System Manufacturer's Operation and Maintenance Manuals. Always read and understand all associated manuals alongside the Heil Parts and Service Manual and Heil Operation Manual.

As the operator of the unit, you have several responsibilities:

- You must have a valid driver's license.
- You must understand and follow all manufacturers' instructions for equipment operation.

- You must observe pertinent laws and regulations.
- Do not use drugs or alcohol while you operate the unit.
- You must read, study and understand all procedures and requirements of this Operation Manual before you operate the unit for the first time. If you do not understand or have difficulty reading this manual, YOU MUST tell the owner or designated person before you operate the unit. DO NOT operate the unit until you understand the procedures and requirements of this manual.
- You must receive proper training before you operate (or service and maintain) the unit. If you have not been trained, you must inform the owner.
- You must perform a daily inspection of the unit before you go on route. Refer to the Daily Checklist 73.
- You must make sure that all decals and labels are clean and readable.
- You must report to the owner (or the designated person) any and all deficiencies, malfunctions or problems you find during the daily inspection.
- You must read, understand and obey all safety messages and decals that are on the outside or in the cab of the unit.

TO THE OPERATOR (CONTINUED)

- Always use your employer's Lock-Out/Tag-Out procedures. If your employer does not have Lock-Out/Tag-Out procedures, use the Lock-Out/Tag-Out Procedure 5 in this manual.
- Before you start the engine or operate the unit for the first time
 - You must clear the area of other people.
 - You must learn and practice safe use of all controls and indicators before you operate the unit in a collection route environment or before you do repair or maintenance procedures.
- Before each time you start the engine or operate the unit, you must clear the area of other people.
- Before you operate the unit in reverse, you must make sure the area behind the unit is clear of other people, vehicles or other obstructions.
- You must make sure the unit is on hard, stable ground when you unload refuse at the landfill or transfer station.

TO THE MECHANIC

Do not operate the unit or perform repair or maintenance procedures on the unit until you read and understand all of the instructions in this manual. Failure to do so may result in injury or death to operators or bystanders and/or damage to the unit or other property.

A unit that needs service or repair can malfunction and create a dangerous condition. A part failure during operation can cause serious injury or death to a person or damage to the unit. Repair or replace any failed or defective part immediately.

NOTICE

If you do not understand a procedure or instruction, tell the owner or the designated person immediately. Do not operate the unit if you do not understand all procedures and instructions in this manual. The owner or designated person can contact your Heil dealer or Heil for additional help. See **Customer Service and Repair Parts Contact Information**

TO THE MECHANIC (CONTINUED)

As the mechanic of the unit, you have several responsibilities:

- You must have a valid driver's license if you operate the unit on a public road.
- You must understand and follow all manufacturers' instructions for equipment operation.
- You must observe pertinent laws and regulations.
- Do not use drugs or alcohol while you service or operate the unit.
- You must read, study and understand all procedures and requirements of this Operation Manual and the Service Manual before you operate the unit for the first time.
- If you do not understand or have difficulty reading this manual or the Service Manual, You must tell the owner or designated person before you operate or service the unit.
- DO NOT operate or service the unit until you understand the procedures and requirements of this manual and the Service Manual.
- You must receive proper training before you operate or service and maintain the unit. If you have not been trained, you must inform the owner.
- You must read, understand, and obey all safety messages and decals that are on the outside or in the cab of the unit.

- Always use your employer's Lock-Out/Tag-Out procedures. If your employer does not have Lock-Out/Tag-Out procedures, use the Lock-Out/Tag-Out Procedure 5 in this manual.
- Before you start the engine or operate the unit for the first time:
 - o You must clear the area of other people
 - You must learn and practice safe use of all controls and indicators before you operate the unit or before you do repair or maintenance procedures.
- Before you operate the unit in reverse, you must make sure the area behind the unit is clear of other people, vehicles or other obstructions.

A unit that needs service or repair can malfunction and create a dangerous condition. A part failure during operation can cause serious injury or death to a person or damage to the unit. Repair or replace any failed or defective part immediately.

WARRANTY CLAIMS AND INQUIRIES

The HEIL ENVIRONMENTAL WARRANTY STATEMENT is printed on the inside, back cover of this manual. Should a failure occur that is covered by this warranty, contact the nearest Heil dealer for warranty repair unless otherwise authorized by Heil.

For all parts, warranty claims, and inquiries, please give the dealer or service center the unit's model and serial number located on the body serial plate. See **Serial Plate Location** page for the location of the body serial plate.

CUSTOMER SERVICE AND REPAIR PARTS CONTACT INFORMATION

Customer Care

Phone: 866-275-4345

Tech Services

Phone: 866-310-4345

Parts Central

Phone: 800-528-5308

4301 Gault Avenue North Fort Payne, AL 35967 www.heil.com

MODELS

The DuraPack[®] Python[®] has four body models:

- Eject
- Service Hoist
- Serviceable Eject (Service Lift)
- Dump

Eject, Service Hoist, and Serviceable Eject (Service Lift) models use a Packer/Eject panel and two cylinders to compact the refuse from the hopper into the body (packer mode) and to push all of the refuse from the body (eject mode).

The Eject and Serviceable Eject (Service Lift) body models do not have Service Hoist Cylinders.

The Serviceable Eject (Service Lift) body model requires an external hoist and cable to raise the body a short distance for service and maintenance operations.

The Service Hoist body model is an Eject body with two service hoist cylinders to raise the body a short distance for service and maintenance operations.

The Dump body model is a Dump body with two hoist cylinders to raise the body to dump and empty the refuse.

SERIAL PLATE LOCATIONS

You determine the sides of the unit by facing the direction of forward travel. The left side is the street side and the right side is the curb side. The figure below shows the location of the serial plate on the streetside of the unit's body. See the next page for a description of the information that is on the serial plate.



Figure 1. Serial Plate Locations

READING THE SERIAL PLATE

The serial plate is the "birth certificate" of the unit. See the figure below.

THE WHEELS ARE ALRAYS TURALS	DuraPack® F	Pythor amily Boo	n® dy
WARRANTED UNE MODEL NO.	DER CURRENT PUBLIS SERIAL NO.	SHED WAR SIZE	RANTY DATE
PATE	ENT WWW.HEIL.COM/PAT	ENTS	212 - 3348

Information stamped in the boxes on the serial plate indicates:

Model number:

612-nnnn-001 is a dump body, -002 is an eject body, and -003 is a service hoist body ("n" is any single-digit number).

Unit's unique serial number

Body size (cu. yd.)

Date of manufacture (last number of the year followed by the number of the day of the year, e.g. 6145 is year 2006 and the 145th day of 2006).

NOTICE

The code for the year of manufacture is in accordance with FMVSS 115. See the following table.

Year of Manufacture			
Year Code	Year	Year Code	Year
5	2005	F	2015
6	2006	G	2016
7	2007	Н	2017
8	2008	J	2018
9	2009	К	2019
А	2010	L	2020
В	2011	М	2021
С	2012	N	2022
D	2013	Р	2023
E	2014	R	2024

PRODUCT NOMENCLATURE

The figure below shows the major components and their typical location on the unit. See the following pages for brief descriptions of each component shown below.



PRODUCT NOMENCLATURE (CONTINUED)

Hydraulic Pump - The unit's hydraulic pump provides the oil flow for the hydraulic system. It is located either in front of the unit's engine or underneath the unit, powered by the transmission through a Power Take-Off (PTO). The pump is activated when the operator turns ON the SYSTEM POWER switch located on the in-cab control panel and is deactivated when the operator turns OFF the SYSTEM POWER switch. Depending on the pump and PTO combination, hydraulic oil may flow through the system when the pump is off, however, the operator controls are inoperative and the system hydraulic oil pressure is not sufficient to operate the unit's functions.

Moving equipment can be dangerous to bystanders. Serious injury or death can occur if a person is in the area of operation or is not attentive to the operations. Clear the area of all unnecessary people before you operate the controls.

Cab Controls – The standard cab control panel is located in the vehicle cab. See **Cab Controls, Switches and Indicator Lights** 59 for the different controls that may be installed in your unit. The standard and optional lift arm controls are located in the cab.

Lift Arm – Use the loader's lift arm to pick up and dump refuse from a refuse container into the hopper. (The loader is the assembly that includes the lift arm, the grabber assembly, hoses and other parts.) The operator can do this either inside the cab with the standard rocker switches, optional rocker switches or an optional joystick.

A DANGER

Do not enter the hopper unless the unit is in the Lock-Out/Tag-Out mode. When the unit is not in the Lock-Out/Tag-Out mode, the packer/ejector panel can be operated. DEATH or SERIOUS INJURY may occur if the packer/ejector panel moves while a person is in the hopper.

Hopper – The hopper is the front part of the body assembly. The packer panel is in the hopper. The hopper is the loading chamber for the refuse. Refuse dumped into the unit falls inside the hopper where it is moved by the packer paddle into the body.

Body – The body stores the compacted refuse until you dump the refuse at the landfill. **DO NOT** enter the body from the hopper.

Body Props – Always use both body props, one on each side of the unit, when you raise the body for maintenance or service procedures.

Make sure hopper area is clear of people on both sides of unit before starting packer cycle. Packer completes one or two cycles when ANY packer EXTEND button is ON or when AutoPack is ON and cart lowers from hopper. Death or serious injury can occur if any part of your body is in the hopper when the panel is in motion.

Packer/Eject Panel & Cylinders – The packer/eject panel is inside the hopper (at the front of the hopper) and has two functions:

- The packer function compacts the loaded refuse from the hopper into the body (packer mode)
- The eject function pushes the loaded refuse out of the body (eject mode) through the open tailgate.

During the PACKER mode, you extend the packer/eject panel cylinders to push the packer panel towards the rear of the body, which compacts the load.

The packer panel has a follower panel, so the operator can dump a container into the hopper no matter where the packer is in the pack cycle.

Normal operation of the AutoPack[™] feature consists of one extension and retraction of the packer panel.

During the EJECT mode, you use the packer/eject panel and cylinders to remove the refuse from the body.

• On the Eject and Service hoist models when the tailgate is open, the EJECT mode lets the packer/eject panel travel further than during the packer mode. This extra travel of the panel removes ALL of the refuse from the body. You do not need to raise the body with an Eject or Service hoist body model to remove the refuse.

A DANGER

Before entering the body area, place the unit in Lock-Out/Tag-Out mode. See Lock-Out/Tag-Out Procedures 55.

The side door must be closed before you start a packer operation. Serious injury or death may occur if a person is inside the body or hopper. Make sure no one is inside the hopper or body before you close the door and begin a packer function.

Side Access Door – Use this street side door to enter the body when required for cleaning or other maintenance tasks. MAKE SURE the unit is in Lock-Out/Tag-Out mode and the keys removed from the ignition and in the operator's control BEFORE you enter through the side door.

The door has a proximity switch that the Cortex Controller[™] uses to disable the hydraulic system unless the door is closed.

A DANGER

Always prop a tailgate when you leave it raised for maintenance, service or cleaning procedures. Any part of your body between the unit's body and the tailgate while you prop the tailgate or when the tailgate is propped is dangerous. Serious injury or death may occur if any part of your body is between the tailgate and the body if the tailgate suddenly closes.

Sump Doors – A sump door is located on the front corner on each side of the body and needs to be open when cleaning out the sump area.

Tailgate Props – Always use both tailgate props, one on each side of the unit, when you raise the tailgate for maintenance or service procedures.

Tailgate Cylinders – You use these cylinders to RAISE the tailgate before you unload the compacted refuse at the landfill. After you unload the refuse, you use the cylinders to LOWER the tailgate.

Tailgate Latches – The unit uses a mechanical latch on each side of the body to lock (latch) the tailgate. A "flag" at the back of the curb side of the body lets the operator see whether the tailgate is locked or unlocked. The flag is UP when the tailgate is FULLY DOWN (and LOCKED) and DOWN when the tailgate is OPEN (UNLOCKED). See **Body and Tailgate Props**

Tailgate Lock Cylinders – Heil's patented Shur-Lock[™] system uses tailgate lock cylinders to UNLOCK the tailgate before you RAISE the tailgate and to LOCK the tailgate after you LOWER the tailgate.

A DANGER

A tailgate in motion is dangerous. Serious injury or death may occur if a person is struck by a moving tailgate or becomes trapped between the tailgate and the body. Clear the area near the tailgate of all unnecessary people before you lower the tailgate.

Tailgate - Raise the tailgate at the landfill or transfer station to unload the refuse.

A red light and an alarm inside the cab let the operator know when the tailgate is raised. The red light illuminates (is ON) and the alarm sounds when the tailgate is RAISED. The light is OFF and the alarm stops when the tailgate is CLOSED.

NOTICE

You must use the tailgate lock cylinder (described previously) to unlock the tailgate in order to raise the tailgate or to fully close (lock) the tailgate.

A DANGER

Keep all parts of your body out from underneath the unit's body and away from the cylinders when raising or lowering the body. Serious injury or death will occur if the unit's body suddenly lowers and traps a part of your body.

A DANGER

Do not raise a body that has refuse while you do maintenance or service procedures. Refuse in the body can make the unit unstable. Always unload refuse from the body before you raise it for maintenance or service procedures. Always use the body props when you raise the body for maintenance or service procedures.

Raising the body with the tailgate closed can damage the underride bumper. The underride bumper can hit the ground when the tailgate is not fully raised before you raise the body. Serious injury or death may occur and also cause damage to the unit.

Body Raise (Body Hoist) Cylinders – Use these two cylinders to RAISE the body and unload compacted refuse out through the raised, open tailgate. After you unload the refuse, you use these cylinders to LOWER the body until it rests on the chassis.

You also RAISE the body with these cylinders to perform service or maintenance on the unit. When you do service or maintenance with the body raised, ALWAYS use the body props. After completion of the service or maintenance procedures, always LOWER the body until it rests on the chassis.

Cortex Controller[™] – The unit has a Cortex Controller. The Cortex Controller monitors critical components and controls operation of the various functions. When the Cortex Controller detects a fault or unsafe condition, it alerts the operator with an indicator light and/or a buzzer alarm. During certain conditions, the Cortex Controller will not allow operation of all functions.

Hydraulic Oil Tank - The tank is the reservoir for the hydraulic oil which operates all hydraulic cylinders described above.

Operating the unit's controls with a suspended load, such as a raised tailgate or a container on a lift mechanism, will allow the load to move even when the hydraulic pump is OFF.

Operator Controls – The standard operator controls for running the components are inside the vehicle cab. See **Controls, Switches, and Indicator Lights** for the different controls that may be installed in your unit.

LIFT NOMENCLATURE

The figure below shows the major components of the lift arm.



Figure 3. Lift Nomenclature

GLOSSARY

TERM	DEFINITION
accident	An incident that results in unintended harm.
AUTO	The command to select the AutoPack feature.
bin	The refuse collection container
body	The complete body assembly or the area of the body where the refuse is stored.
CAUTION	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
collapsed position	The fully retracted position of a cylinder
Cortex Controller™	Heil Electronic Body Controller (Half/Pack [®] , Half/Pack [®] Freedom, Half/Pack [®] Sierra, Odyssey™ HP/HPF/HPS, DuraPack [®] Python [®] , DuraPack [®] Rapid Rail [®] , DuraPack [®] 7000, MultiPack [®] , Rapid Rail [®] , and STARR [®] System units only).
Auto-Lift	A feature of the Python [®] loader that automatically lifts and dumps a container, then automatically removes the container from the hopper and brings the lift arm down.
DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
extend/EXTEND	Make a cylinder rod move out its base / Command to move the packer panel towards the body
fouling	Damage to the lid(s) of the refuse bins (containers) that interferes with unloading the refuse
front head	The part of the body that allows access to the body from the front of the body. This is the ONLY access to the body when the unit does not have an optional side access door.
fully retracted position	The packer/extend cylinder is fully retracted and the packer panel is all the way to the front of the hopper. May also be referred to as "Home Position" or "Front Head".
grabber	The entire grabber assembly or the grabber arms.
GRIP	The command to close the grabber arms around a refuse container.

GLOSSARY

TERM	DEFINITION
harm	An action that causes death, injury or property damage.
hazard	A potential source of harm.
hopper	The loading chamber of the unit in front of the packer panel where you dump the refuse material.
illuminate	Make a lamp shine light (the lamp is on).
incident	An unintended and undesired event that has the potential to harm.
interlock	A safety mechanism that disables a function or action.
LATCHED	The condition when the tailgate is fully CLOSED, thereby locking the tailgate.
LOCK	Command to use the tailgate lock/unlock switch and lock the tailgate lock cylinders.
must	The action is mandatory.
NOTICE	Alerts you to practices not related to personal injury, such as damage to the unit or other equipment.
off/OFF	When a light or lamp does not illuminate / The position of a switch or other control to stop a function
on/ON	When a light or lamp illuminates / The position of a switch or other control to start a function
operator	Any person who uses the unit and its equipment. One who controls the operation of various unit accessories and mechanisms, loads material, performs functions such as operating the loader, cart tipping and packing of wastes or recycled products, and who may also drive the unit along the route during the collection process. The operator may also be the driver.
PN	Part Number
PTO	Power Takeoff

GLOSSARY

TERM	DEFINITION
retract/RETRACT	Make a cylinder rod go into its base / Command to move the packer panel towards the hopper
RPM	Revolutions Per Minute
Select-O-Pack™	The Select-O-Pack feature allows the operator to set the number of lift cycles before automatic operation of the packer.
side access door	The side access door is located on the street side of the unit. This is the preferred access into the body. ALWAYS Lock-Out/Tag-Out 55 the unit BEFORE entering the body.
top door (hopper cover)	This optional top door covers and uncovers the hopper. The cover is closed during transit and must be open during loading of refuse in the hopper.
unit	The Heil DuraPack [®] Python [®] refuse collection vehicle referred to in this manual.
UNLATCHED	The side access door is not closed or secured.
UNLOCK	Command to use the tailgate lock/unlock switch and unlock the tailgate lock cylinders
WARNING	Indicates a hazardous situation, which if not avoided, could result in death or serious injury.

SECTION 2 SAFETY MESSAGES AND DECALS

Copyright 2017, Heil Environmental Printed in U.S.A.

PREVIEW

Read this section to learn about:

- General safety precautions and safety precautions for the safe operation and maintenance of the unit
- The safety precautions for NOT towing another vehicle or machine
- Safety decals on the unit.

DuraPack[®] Python[®]

PRECAUTIONARY STATEMENTS

Read this entire manual and especially this safety section before you operate the vehicle. Failure to follow these important precautions could result in serious injury, death, or property damage.



This safety alert symbol indicates important safety messages in this manual and on safety decals attached to the equipment. Make sure you read all of these messages and follow the instructions and precautions.

In the general text of the manual and in the safety labels attached to the product, signal words indicate the type and seriousness of risk that you could encounter if you do not follow the precautions. The signal words and their definitions follow:

DANGER

DANGER indicates a hazardous situation which, if not avoided, WILL result in DEATH or SERIOUS INJURY.

WARNING indicates a hazardous situation which, if not avoided, COULD result in DEATH or SERIOUS INJURY.

CAUTION indicates a hazardous situation which, if not avoided, COULD result in MINOR or MODERATE INJURY.

NOTICE

NOTICE addresses practices not related to personal injury, such as property damage or damage to the equipment.

The following pages provide a summary of some of the more important safety precautions that are in this manual. There are additional safety precautions in other sections of this manual that are not contained in this section. You must also read. understand and follow those messages.

GENERAL SAFETY PRECAUTIONS

- **DO NOT** operate the unit under the influence of alcohol or drugs or when extremely tired or when you are not alert, as this may result in an accident that can cause serious injury or death.
- **DO NOT** operate the unit unless you have the proper training and vehicle operator license.
- ALWAYS carry and maintain a fire extinguisher and first aid kit in the unit. MAKE SURE you know how to use them.
- CLEAN AS NECESSARY any safety decals that you cannot read at a safe viewing distance from the hazard because of dirt. If any decals are illegible from damage or wear, REPLACE them IMMEDIATELY. Get decals from your Heil dealer or Heil.
- **DO NOT** use this refuse collection vehicle to TOW another vehicle or equipment. It **IS NOT DESIGNED** or equipped to tow another vehicle or other equipment. Towing another vehicle or equipment may result in injury or death to the operator or other people or damage to the unit.
- MAKE SURE all individuals are clear of any moving parts, mechanisms or components of the unit before you operate the controls.

- **DISENGAGE** the PTO or PUSH the SYSTEM POWER switch so the pump shuts off when you are not using the unit, when you are repairing the unit, when you are working on the unit, or when traveling in the unit for longer than two minutes.
- ENGAGE the PTO or PULL the SYSTEM POWER switch ONLY when you are on route OR as necessary to perform repairs.
- When the unit is stored or not in use, you **MUST** do the following:
 - SET ALL lift cylinders (including the body raise cylinders) to the collapsed position.
 - For units with manual transmissions, DISENGAGE the PTO and PUSH the PUMP switch so it shuts off the pump.
 - For units with automatic transmissions PUSH the SYSTEM POWER switch so the pump shuts off.
 - **REMOVE** the key from the ignition. This helps prevent tampering by unauthorized persons.
 - Refer to Lock-Out/Tag-Out Procedure 55.
- You must be attentive at all times while you operate the controls and be ready to stop or reverse the function if necessary.
A BEFORE OPERATING THE EQUIPMENT

- **DO NOT** operate or service this machine until you are fully trained and have read and understand this entire manual.
- NEVER operate the unit UNLESS you are fully knowledgeable of all control functions. See the Controls, Switches, and Indicator Lights 59 section of this manual.
- MAKE SURE BEFORE you operate the vehicle or its controls that all individuals are at a safe distance away from the unit.
- DO NOT operate the unit when it needs service or repair.
- DO A VISUAL CHECK at the beginning of each shift of the unit and run it through several cycles to find fluid leaks, broken, missing or malfunctioning, and excessively worn components (including hoses). See the **Daily Checklist** section 73 of this manual. If you find leaks, broken, missing or malfunctioning parts, immediately stop and get the condition repaired or serviced.

A USE PERSONAL PROTECTIVE EQUIPMENT

- ALWAYS WEAR the proper safety equipment, such as hard hats, safety shoes, protective eye wear, reflective clothing and gloves. Confirm with the owner/operator that you are using proper safety equipment.
- WEAR PROPER EYE PROTECTION and avoid contact with oil if possible whenever you work on or about hydraulic lines or components. NEVER check for oil leaks with your bare hands.

A BEWARE OF OVERHEAD OBSTRUCTIONS

- KNOW the clearance required for ALL overhead obstructions (such as viaducts and bridges) that you may encounter when you drive the unit. See the decal in the chassis cab for your unit's overall height.
- **NEVER** drive the unit under any overhead obstruction of unknown height clearance.
- Become familiar with your route. Be aware of all overhead trees and obstructions that could cause problems during refuse collection.
- **CHECK** the height of the unit after you do any modifications to the chassis suspension. Any chassis suspension modification may change the height of the unit. See Tables 1 and 2.

- LOOK UP AND LIVE. MAKE SURE there is enough clearance between a lowered or raised container and overhead power lines. It is not necessary for the unit or container to touch the electric cable for the electricity to pass through the unit. See Tables 1 and 2.
- STAY IN THE CAB and KEEP AWAY FROM ALL METAL PARTS OF THE UNIT if the unit does touch a power line. STAY IN THE UNIT UNTIL HELP ARRIVES.

OVERHEAD CLEARANCES

NOTICE

Table 1 and 2 is in accordance with OSHA 29CFR 1910.333. (Also refer to ANSI Standard B30.5-2004, 5-3.4.5.) If local rules and laws require more clearance, you must follow them.

Table 1. Overhead Clearances When Operating the Unit

Voltage of Electric Line	Minimum Clearance
50,000 or less	10 feet (3 m)
Above 50,000 to 200,000	15 feet (4.6m)
Above 200,000 to 350,000	20 feet (6.1 m)
Above 350,000 to 500,000	25 feet (7.6 m)
Above 500,000 to 750,000	35 feet (10.7 m)
Above 750,000 to 1,000,000	45 feet (13.7 m)

Table 2. Overhead Clearances When Driving the Unit

Voltage of Electric Line	Minimum Clearance
750 or less	4 feet (1.2 m)
Above 750 to 50,000	6 feet (1.8 m)
Above 50,000 to 345,000	10 feet (3 m)
Above 345,000 to 750,000	16 feet (4.9 m)

Table 2. Overhead Clearances When Driving the Unit

Voltage of Electric Line	Minimum Clearance		
Above 750,000 to 1,000,000	20 feet (6.1 m)		

LOADING REFUSE INTO THE UNIT

- YOU MUST BE ATTENTIVE at all times when you load refuse and be ready to stop or reverse the function in use if necessary.
- ALL PERSONS MUST STAND CLEAR when the tailgate is in motion and during the unloading cycle. MAKE SURE no one stands under or crosses under a raised tailgate.
- LOOK UP AND LIVE. Make sure there is enough clearance between a raised container and overhead power lines. Refer to Tables 1 and 2.

- MAKE SURE the unloading area is clear of all personnel.
- ALL PERSONS MUST STAND CLEAR when the tailgate is in motion and during the unloading cycle. MAKE SURE no one stands under or crosses under a raised tailgate.
- While you raise the body, be attentive at all times and be ready to stop or reverse the function if necessary.

WHEN WORKING IN OR AROUND THE VEHICLE

- MAKE SURE the unit is in Lock-Out/Tag-Out 55 condition BEFORE you work in or around the unit.
- **NEVER** put any part of your body between a raised body and the chassis frame unless the frame is securely propped up. Read and follow the instructions for **Propping the Body** 87.
- **DO NOT** go under the chassis or enter the body area unless the unit is locked-out. To lock-out the unit, stop the engine, apply the brakes and make sure the brakes hold and work properly, chock all wheels, remove the keys from the cab, and place a lock-out tag on the steering wheel. See **Lock-Out/Tag-Out Procedure 55**.



• Heil DOES NOT recommend that you tow any kind of equipment with the unit. The unit was NOT DESIGNED nor intended for towing.

DECALS

The following pages show the DANGER, WARNING and CAUTION decals and list the reflective safety materials that are on the vehicle. See the Parts and Service Manual for the location and part numbers of all decals on the unit.

NOTICE

Replace any decal with a new decal if the old decal is lost, destroyed, painted over or cannot be read. When you replace a part that had decals, make sure you install new decals on each new part. Decal part numbers can be found below and in the Parts Manual. You can purchase replacement decals from your **Heil Dealer** or from the **Heil Parts Central**, 800-528-5308.

REFLECTIVE SAFETY MATERIALS

See the Parts and Service Manual for the location and part numbers of the reflective safety materials on the unit.

NOTICE

Replace any safety material with new safety material if the old safety material is lost, destroyed, painted over or cannot be seen. When you replace a part that had safety material on it, make sure you install new safety material on the new replacement part. See the Parts and Service Manual for all part numbers and location of the safety materials.

You can purchase replacement decals from your Heil Dealer or from the Heil Parts Central, 800-528-5308.

DuraPack[®] Python[®]

DUMP/SERVICE HOIST DECAL PLACEMENT



DETAIL B

Issued September 2017 Safety Messages and Decals

Copyright 2017, Heil Environmental Printed in U.S.A.

DUMP/SERVICE HOIST DECAL PLACEMENT (CONTINUED)



DETAIL D

DUMP/SERVICE HOIST DECAL PLACEMENT (CONTINUED)

ITEM	PART NO.	DESCRIPTION	EFF	QTY
-	212-2407	INSTALLATION, Decal, Dump/Service Hoist		REF
1	212-0980	DECAL, Danger, Stay Clear, Container Off Ground		1
2	212-1103	DECAL, Danger, Body Elevated, Lg.		2
3	212-1104	DECAL, Danger, Body Elevated, Small		1
4	212-1242	DECAL, Danger, Stand Clear, Automated Lift Device In Motion		1
5	212-1329	DECAL, Instruction, Body Prop		2
6	212-1330	DECAL, Warning		1
7	212-1584	DECAL, Overall Height		1
8	212-1626	DECAL, Danger, Tailgate Raise, Before Body		1
9	212-1631	DECAL, Warning, Bumper, Not Step		1
10	212-1634	DECAL, Danger, Stand Clear		1
11	212-1642	DECAL, Danger, Top Hopper and Tailgate Opening		5
12	212-1764	DECAL, Danger, Under Chassis, Stop Engine		2
13	212-1780	DECAL, Caution, Side Door		1
14	212-1781	DECAL, Caution, Enter Body, Stop Engine		1
15	212-1782	DECAL, Hydraulic Oil Only		1
16	212-1783	DECAL, Warning, Operator's Manual		2
17	212-1801	DECAL, Danger, Stand Clear		3
18	212-1820	DECAL, Danger, Towing, In Cab		2
19	212-1841	DECAL, ANSI Specifications		1
20	212-1907	DECAL, Danger, Access Door		1
21	212-1911	DECAL, Caution, Panel In Motion		1
22	212-1914	DECAL, Caution, Ladder		1
23	212-1915	DECAL, Warranty Parts		1
24	212-1918	DECAL, Safety Instructions		1
25	212-2228	DECAL, Proximity Switch, Adjustment		5
26	212-2275	DECAL, Oil Level		1
27	212-2338	DECAL, Packer/Ejector Adjustment		1
28	212-2404	DECAL, Lubrication Guide		1
29	212-2605	DECAL, Sump Door		1
30	212-2689	DECAL, Flag		1
31	212-2738-010	DECAL, Auto/Manual Mode, Python lift		1

DUMP/SERVICE HOIST DECAL PLACEMENT (CONTINUED)

ITEM	PART NO.	DESCRIPTION	EFF	QTY
32	212-2875	DECAL, Battery, Warning		1
33	212-2920-002	DECAL, Lubrication Guide, Light Weight, Python Lift		1

EJECT DECAL PLACEMENT



DETAIL B

EJECT DECAL PLACEMENT (CONTINUED)



DETAIL D

EJECT DECAL PLACEMENT (CONTINUED)

ITEM	PART NO.	DESCRIPTION	EFF	QTY
-	212-2960	INSTALLATION, Decal, Eject		REF
1	212-0980	DECAL, Danger, Stay Clear, Container Off Ground		1
2	212-1103	DECAL, Danger, Body Elevated, Lg.		2
3	212-1104	DECAL, Danger, Body Elevated, Small		1
-4	212-1242	DECAL, Danger, Stand Clear, Automated Lift Device In Motion		1
5	212-1329	DECAL, Instruction, Body Prop		2
6	212-1330	DECAL, Warning		1
7	212-1584	DECAL, Overall Height		1
8	212-1626	DECAL, Danger, Tailgate Raise, Before Body		1
9	212-1631	DECAL, Warning, Bumper, Not Step		1
10	212-1634	DECAL, Danger, Stand Clear		1
11	212-1642	DECAL, Danger, Top Hopper and Tailgate Opening		5
12	212-1764	DECAL, Danger, Under Chassis, Stop Engine		2
13	212-1780	DECAL, Caution, Side Door		1
14	212-1781	DECAL, Caution, Enter Body, Stop Engine		1
15	212-1782	DECAL, Hydraulic Oil Only		1
16	212-1783	DECAL, Warning, Operator's Manual		2
17	212-1801	DECAL, Danger, Stand Clear		3
18	212-1820	DECAL, Danger, Towing, In Cab		2
19	212-1841	DECAL, ANSI Specifications		1
20	212-1907	DECAL, Danger, Access Door		1
21	212-1911	DECAL, Caution, Panel In Motion		1
22	212-1914	DECAL, Caution, Ladder		1
23	212-1915	DECAL, Warranty Parts		1
24	212-1918	DECAL, Safety Instructions		1
25	212-2228	DECAL, Proximity Switch, Adjustment		5
26	212-2275	DECAL, Oil Level		1
27	212-2338	DECAL, Packer/Ejector Adjustment		1
28	212-2404	DECAL, Lubrication Guide		1
29	212-2605	DECAL, Sump Door		1
30	212-2689	DECAL, Flag		1
31	212-2738-010	DECAL, Auto/Manual Mode, Python lift		1

EJECT DECAL PLACEMENT (CONTINUED)

ITEM	PART NO.	DESCRIPTION	EFF	QTY
32	212-2875	DECAL, Battery, Warning		1
33	212-2920-002	DECAL, Lubrication Guide, Light Weight, Python Lift		1

DECAL IMAGES



Figure 4. Danger: Stay clear container off ground, PN 212-0980



Whenever the body is in any elevated or raised position, it must first be emptied and then securely blocked or propped so it cannot lower, which may cause injury or death!

Figure 5. Danger: Elevated body emtpied and propped, PN 212-1103



Figure 6. Danger: Stand clear automatic lift, PN 212-1242

ADANGER

Whenever the body is in an elevated or raised position it must be securely propped or blocked so it can not fall on anyone. Failure to do so may result in injury or death.

212-1104

Figure 7. Danger: Elevated body propped, PN 212-1104

DECAL IMAGES (CONTINUED)



Figure 8. Danger: Stand clear tailgate, PN 212-1801

AWARNING Never Use The Bumper As A Riding Step.

Figure 9. Warning: Never use bumper as step, PN 212-1631

212-1631



Figure 10. Danger: Stand clear tailgate, PN 212-1634

A PELIGRO

NO PASE POR ABAJO EL CHASIS DEL CAMION SI EL MOTOR O MAQINA DE PODER NO ESTAN APAGADOS, Y LA LLAVE NO HA SIDO QUITADA DE LA IGNICION.



A DANGER

Do not enter under chassis unless engine or power units are stopped and ignition keys are removed.

Figure 11. Danger: Do not enter under chassis, PN 212-1764

DECAL IMAGES (CONTINUED)

WARNING

STOP ENGINE AND REMOVE IGNITION KEY. LOCKOUT / TAGOUT REQUIRED BEFORE ENTERING.

ADVERTENCIA

DETENGA EL MOTOR Y RETIRE LA LLAVE DE ENCENDIDO. BLOQUEO / ETIQUETADO ES NECESARIO ANTES DE ENTRAR. 212-1781

Figure 12. Warning: Lock-out / Tag-out, PN 212-1781



MANTENGA LA PUERTA DE ACCESO CERRADA MIENTRAS QUE EL PANEL EYECTOR ESTE EN MARCHA Y EN MOVIMIENTO. FALTA DE HACERLO PUEDE RESULTAR EN UNA HERIDA O MUERTE.

ADANGER

Keep access door closed when ejector panel is in operation and in motion. Failure to do so may result in injury or death.

Figure 13. Danger: Access Door Closed, PN 212-1907



Figure 14. Caution: Side Access Door, PN 212-1780

A DANGER

The top hopper opening and tailgate opening should not be used as an entrance or exit to the body as it could result in personal injury or death.

Figure 15. Danger: Not an entrance or exit, PN 212-1642

DECAL IMAGES (CONTINUED)

WARNING

Do not operate or service this machine until you have read and fully understand the operations manual supplied with this equipment. Manuals can be obtained from a HEIL CO. Distributor.

212-1783

ADVERTENCIA

NO SE DEBE OPERAR O MANTENER ESTAMAQUINA HASTA QUE HAYA LEIDO Y COMPRENDIDO EL MANUAL DE OPERACION ENTREGADO CON ESTE EQUIPO. MANUALES TAMBIEN PUEDEN SER CONSEGUIDOS POR MEDIO DEL DISTRIBUIDOR DE THE HEIL CO.

THE HELCO.

Figure 16. Warning: Operations Manual, PN 212-1783



Figure 17. Caution: Stand Clear Panel, PN 212-1911



WARNING THE BATTERY DISCONNECT SWITCH MUST BE TURNED OFF WHENEVER THE VEHICLE IS NOT IN SERVICE AND/OR TO BE LEFT UNATTENDED! Battery Cables must be securely anchored and not rubbing other equipment. Cable insulation must be free of damage and abrasion. Inspect weekly. 212-2875

Figure 19. Warning: Battery disconnect switch, PN 212-2875



safety/balance, PN 212-1914

Issued September 2017 Safety Messages and Decals

DuraPack[®] Python[®]

DECAL IMAGES (CONTINUED)

BODY PROP OPERATION

AWARNING

Body must be unloaded before using props. DO NOT MOVE truck while the body is resting on the body props. Two props are installed on the vehicle. BOTH props must be used!

TO USE PROPS:

- Raise body to a height where props can be swung into position.
 Raise body to a height where props can be swung into position.
 Remove transit position body prop retainers and swing body props to support position.
 Lower body until body props support the weight and visually inspect to see that props are located on the saddles and secure.
- Place unit in Lock-Out/Tag-Out mode before performing any work. NOTE: Hoist is single acting (lowered by gravity only).

A DANGER

Do not enter under the body area unless the unit is in Lock-Out/Tag-Out mode. To place unit in Lock-Out/Tag-Out mode, stop the engine, set the brakes and make sure the brakes are holding and working properly, chock all wheels, _remove the keys from the cab, place keys in a secure location, and insert a Lock-Out Tag on the steering wheel

TO STORE PROPS:

1. Raise body slightly. 2. Return props to transit position and install retainers.

212-1329

Figure 21. Danger: Body Prop Operation, PN 212-1329



Figure 22. Warning: **Overall height, PN** 212-1584



Figure 23. Warning: Keep away from gear, PN 212-1330

ADANGER

Always raise tailgate before raising body to prevent bumper from hitting ground. Failure to do so may result in unit damage, personal injury, or death. 212-1626

Figure 24. Danger: Raise Tailgate before Raising Body, PN 212-1626

DECAL IMAGES (CONTINUED)

PACKER/EJECTOR PANEL ADJUSTMENT UNITS with AUTOPACK ONLY

This adjustment should be made with the hydraulic system at operating temperature and the engine RPM held at a level to cause the packer panel to move at its fastest speed during retract. RETRACT STROKE

 Adjust the retract proximity switch so the packer panel retract functionshuts off and the panel comes to rest2 inches away from the front head(outside proximityswitch located on the front head). Do not let the packer panel touch the front head (no slamming).

2.After the stroke has been set, cycle the panel a final time. When the panel stops retracting, manually press the retract button and not the travelleft between the packer panel and the front bulkhead. On some units, the outside proximity switch must be disconnected before manually pressing the retract button. If travel is less than 2 inches, repeat step 1.

EXTEND STROKE

 Extend the packer panel until the rollers on the packer follower stop and rest at the end of the fixed panel guides.

 Adjust the full extend proximity switch (inside proximity switch located on the front head) so the retract portion of the autopack cycle starts just before the panel follower rollers leave the fixed panel guides. This will leave about 58 inches of packer extend stroke.



Figure 25. Warning: Packer/Ejector Panel Adjustment, PN 212-2338

THIS UNIT CONFORMS TO ALL PRESENT AMERICAN NATIONAL STANDARDS INSTITUTE SAFETY REQUIREMENTS Z245.1 IN EFFECT ON THE DATE OF MANUFACTURE.

ESTA MAQUINA ESTA DISENADA CONFORME CON LAS NORMAS DE SEQURIDAD Z 245.1 DE LA AMERICAN NATIONAL STANDARDS INSTITUTE EN VIGOR A LA FACHA DE SU MANUFACTURA. 212-1841 THE HEIL CO.

Figure 26. ANSI Specifications, PN 212-1841



DECAL IMAGES (CONTINUED)

SAFETY INSTRUCTIONS INSTRUCCIONES DE SEGURIDAD

THIS VEHICLE IS EQUIPPED WITH A BACK-UP ALARM. WHEN BACKING, THE ALARM MUST SOUND THE OPERATOR IS RESPONSIBLE FOR THE SAFE USE OF THIS VEHICLE.

ESTE VEHICULO ESTA EQUIPADO CON UNA ALARMA DE RETROCESO. CUANDO EN RETROCESO, EL ALARMA TIENE QUE SONAR EL OPERADOR ES RESPONSABLE POR USAR ESTE VEHICULO EN FORMA SEGURA. 212-1918

Figure 28. Safety Instructions, Back-up Alarm, PN 212-1918



Figure 29. Warning: Proximity Switch Adjustment, PN 212-2228





Figure 31. Hydraulic Oil Only, PN 212-1782

DECAL IMAGES (CONTINUED)



Figure 32. Flag, Made in the USA, PN 212-2689



Figure 33. Keep Sump Door Closed, PN 212-2605



Figure 34. Auto/Manual Mode, Python Lift, PN 212-2738-010

THIS UNIT CONFORMS TO ALL PRESENT AMERICAN NATIONAL STANDARDS INSTITUTE SAFETY REQUIREMENTS Z245.1 IN EFFECT ON THE DATE OF MANUFACTURE.

ESTA MAQUINA ESTA DISENADA CONFORME CON LAS NORMAS DE SEQURIDAD Z 245.1 DE LA AMERICAN NATIONAL STANDARDS INSTITUTE EN VIGOR A LA FACHA DE SU MANUFACTURA. 212-1841 THE HEIL CO.

Figure 35. Safety Requirements, ANSI, PN 212-1841

DuraPack[®] Python[®]

DECAL IMAGES (CONTINUED)



Issued September 2017 Safety Messages and Decals 2

CARE OF DECALS

It is important that the decals are properly cleaned to make sure that they are readable and do not come off the unit. Use the following steps to clean the decals.

General Instructions

- Wash the decals with a blend of mild car wash detergent and clean water.
- Rinse with clean water.
- Let the vehicle air-dry or dry with a micro-fiber cloth.
- Do not allow fuels to stay in contact with the decal for an extended period of time. Remove the fuel contamination as quickly as possible.
- Do not use carnauba-based wax over the decals.
- Do not use a mechanical brush while washing the decals.

Pressure Washer Precautions

- Pressure washing can cause damage to decals. It can cause the edges of the decals to lift and peel the decal away from the unit. Over time, the decal can fade, crack or chip away.
- See the following figures for correct and incorrect methods of pressure washing.
- Use pressure washing only when other cleaning methods are not effective. If you use a pressure washer, use the following precautions.
 - Spray nozzle opening: 40° wide pattern
 - o Spray angle: 65° from vehicle's body
 - o Distance of nozzle to decal: 15" minimum
 - Water pressure: <= 800 psi
 - o Length of time: not more than 30 sec.
 - o Do not use sharp angles to clean the decals this can lift the decals from the unit.
 - NEVER use a "turbo pressure nozzle".



ALTERNATIVE CLEANING PROCEDURE

When normal cleaning procedures do not remove difficult debris from the decals, try the following:

Isopropyl alcohol is flammable and is harmful to eyes and skin. Keep isopropyl alcohol away from heat or open sources of ignition. Flush eyes and skin with water for 15 minutes after contact. Seek immediate medical help.

- Spot clean the decal with Isopropyl Alcohol and a micro-fiber cloth (rag).
- If these methods do not work on a problem area, call a Heil Dealer or Heil Customer Service.

NOTES:

SECTION 3 LOCK-OUT/TAG-OUT PROCEDURE

Copyright 2017, Heil Environmental Printed in U.S.A.

PREVIEW

Read this section to learn about the proper Lock-Out/Tag-Out procedures.

You MUST Lock-Out/Tag-Out a unit BEFORE:

- You enter the body
- Do maintenance or repair procedures.

LOCK-OUT/TAG-OUT PROCEDURE

NOTICE

Always use your employer's Lock-Out/Tag-Out procedures. If your employer does not have Lock-Out/Tag-Out procedures, use the procedures that follow. Contact your supervisor or Heil Technical Service if you have any questions about Lock-Out/Tag-Out procedures.

Put the unit in a Lock-Out/Tag-Out mode:

- BEFORE you enter the unit's body.
- BEFORE you perform maintenance, repair, or cleaning procedures on the unit.

☑ Follow These Steps:

- 1. APPLY the brakes. MAKE SURE the brakes do not let the unit move and they work properly.
- 2. Chock all wheels.
- 3. **SET the tailgate props** sheet when you raise the tailgate for service, maintenance or cleaning.
- 4. If equipped, **SET the body props** (88) when you raise the body for service, maintenance or cleaning.
- 5. When there are in-cab controls, turn the ignition switch to ON, then:

- a. Move the switches of the hydraulic controls. This relieves the pressure in the cylinders.
- b. Turn the ignition switch to OFF.
- 6. When there are no in-cab controls, move the outside control levers to relieve the pressure in the cylinders.
- 7. Put a LOCK-OUT/TAG-OUT tag onto the steering wheel.
- 8. Remove the ignition key from the cab, lock the vehicle, and put the key in a secure location.



Figure 40. Lock-Out/Tag-Out Tag (Do Not Operate Tag)

NOTICE

You can order Lock-Out/Tag-Out tags (Part No. 212-1586) through your Heil dealer or through Heil.

NOTES:

SECTION 4 FEATURES, CONTROLS, SWITCHES, AND INDICATOR LIGHTS

PREVIEW

Read this section to learn about the operation of the in-cab and outside controls, switches, buttons, and indicator lights.

NOTICE

The location and appearance of the controls may be different than those shown in this manual. Make sure you know the location of the controls and the how you operate the controls on your unit before you use the vehicle.

This section tells you:

- · Learn about the unit's features and operation specifications
- The in-cab cab controls, switches and buttons
- How the in-cab controls work
- The in-cab indicator lights available
- The outside controls and how they work

FEATURES

InSight™ Diagnostic Display

The Cortex Controller[™] uses the Insight[™] Diagnostic Display for displaying the current status of Input/Output, Engine speed, Temperatures, etc. This can also be used for configuring or selecting different options in the Cortex Controller.

For more information on the Insight Diagnostic Display, refer to Cortex Controller and Service Manual Automated Side Loader Cortex Controller Program 109-0285.

Auto-Lift Mode

Auto-Lift Mode is standard on all Cortex Controller controlled Python units. While in Auto Mode, the lift will automatically retract and dump when holding the grabber close push button.

To toggle the control between Auto and Manual Lift Modes with the System Power switch buttons simultaneously until the in cab alarm stops sounding.

Refer to **Operation Specifications** and **Lifting and Loading Refuse with the Python Lift Arm** for more information.

<u>Select-O-Pack™</u>

Select-O-Pack is a standard feature on all Cortex Controller™ controlled Heil DuraPack Automated Side Loaders. This feature automatically cycles the Auto-Pack after a predetermined number of lift cycles.

Refer to **Operation Specifications** 63 and **Compacting the Load** 110 for more information.

To set the number of lift cycles before automatic operation of the packer, follow these steps.

- 1. Turn the SYSTEM POWER switch OFF.
- 2. Press and hold the packer retract button for five (5) seconds. The in-cab alarm will begin to sound on the fifth second.
- 3. Each additional activation of the retract button will allow one additional lift cycle before automatically packing the load. If no further activation's of the packer retract button is performed, the Select-O-Pack function will be disabled.
- 4. Turn SYSTEM POWER switch ON.

You can also pack the refuse manually any time after loading the refuse in the hopper. You can use the in-cab controls for the packer panel to compact the load again with a manual cycle.

Auto/Manual Pack Mode

Auto/Manual Pack Mode is a standard feature on all Cortex Controller controlled products. While in Auto Mode, the packer will complete its cycle automatically with a momentary activation of the packer extend push button. While in manual mode, it will be necessary to hold the packer extend or retract buttons in order to keep the packer cycling.

Also while in manual mode, all control interlocks will be disabled. This is only intended for special occasions when an operator needs to bypass the control interlocks.

To toggle the control between Auto and Manual Pack Modes with the System Power (E-Stop) button ON, PRESS and HOLD the Packer Extend and Retract buttons simultaneously until the in cab alarm stops sounding.

UNIT INTERLOCKS

There are several interlocks provided to keep a specific function from operating when certain conditions exist. This will affect the operation of the unit and these conditions are as follows.

- Pump Overspeed Interlock the Cortex Controller[™] is programmed to disengage the hydraulic pump when the engine speed exceeds a specific RPM (dependent on chassis) with the transmission in gear and the service brake applied. The pump will reengage when the engine speed drops below a specific RPM (again, dependent on chassis).
- Side Door Interlock If the side door is open, the hydraulic pump will not operate. The pump will operate only after side door is fully closed and the SYSTEM POWER switch is shut off and turned on again.
- 3. Filter Bypass Shutdown Interlock If the hydraulic oil filter becomes contaminated, the hydraulic pump will shut-off. If the oil filter element is not replaced within six hours of bypass condition, the pump will only operate in 3-minute intervals. This 3-minute interval can be reset by cycling the pump switch off, then on again.
- 4. High Transmission Temperature Interlock (Option) this interlock prevents operation of the pump when the transmission fluid temperature exceeds a safe operating range. The pump will not engage for three minutes after the transmission fluid has cooled to within operating range.

- Hydraulic Pump Shutdown Interlock this interlock prevents normal operation of the hydraulic pump when the Cortex Controller[™] has become unable to correctly detect engine speed.
 - 6. Lift Interlock for Joystick Control this interlock prevents two items from normal operation.
 - a. Grabbers Open Interlock (Option) prevents them from being opened with the lift in the raised position.
 - b. Lift Raise Interlock (Option) prevents the lift from raising when a specific grabber pressure is reached.
 - 6. Lift Interlock after raising the tailgate and extending the packer to eject or dump the load, the packer must be retracted to the front head before the lift will raise the first time.
 - 7. Packer Interlock the packer will not extend past the full extend switch unless the tailgate is open.

OPERATION SPECIFICATIONS

Pump System

- The pump will be on only when the in-cab red SYSTEM POWER switch is activated, the hopper side door is closed and locked, and the filter is not in by-pass mode.
- The pump will be active when the above conditions are met and the packer is activated.
- The lift will function in neutral or in gear when foot brake is applied and the RPM is below 900.
- The lift will grab, lift, lower and release in 6-8 seconds at engine idle (700 RPM).

Packer

- The packer will complete one cycle (extend and retract) in 12-14 seconds at 1200 RPM.
- The packer will slow during lift operation.
- The packer will function at any RPM.

<u>Select-O-Pack™</u>

• Triggered off the grabber release push-button, this system initiates a pack cycle once the programmed number of lift cycles have been completed. (Factory pre-set is two (2) lift cycles). See **Features** and **Compacting the Load** and **Compacting the Lo**

<u>Auto-Lift</u>

- Toggle On/Off by holding grip and release buttons simultaneously five (5) seconds (until the in cab alarm stops sounding).
- Closing grabbers will initiate Auto-Lift sequence. Must hold grabber closed button to continue cycle.
- Cart will raise and retract automatically to the dump position.
- Operator manually replaces cart to desired position on the ground
- Pressing and holding grabber release (open) button will return lift to stowed position.
- See Features and Lifting and Loading Refuse with the Python Lift Arm for more information.

OPERATION SPECIFICATIONS (CONTINUED)

Warning Signals

- The arm extended light will activate any time the arm is extended or grabbers are not fully open.
- The arm extended light and alarm will activate when the arm is extended or grabbers are not fully open, the transmission is in gear and the foot brake is not applied.
- An alarm will sound and a light will illuminate if the body or tailgate are raised.
- The backup (reverse) alarm will sound if the body or tailgate is raised or the transmission is in reverse.

California Specific Warning Signals

• The California backup (reverse) alarm will sound with ignition off and the battery disconnect switch on.

Waste Management Specific Interlocks

- Arm will not raise with grabbers open.
- Grabbers will not open with arm raised
- Arm will not raise with hopper cover not fully open
- Lift will not raise with tailgate open.
- Lift will not function unless joystick sensor indicates that operator is grasping joystick.
- Road speed will not exceed 15 MPH with lift not stowed.
IN-CAB MAIN CONTROL PANEL

The In-Cab Main Control Panel can vary with different models of truck chassis. See the figure below for an illustration of a typical control panel. The control panels have labels or markings that identify each function and its operations. Make sure you are familiar with the control panel in your unit.

The labeling/marking scheme is straight-forward and identifies a function and its operations. Refer to the numbered callouts on the figure below and the corresponding description of each switch, button, and light on the following pages.



Figure 41. Control Panel

IN-CAB MAIN CONTROL PANEL (CONTINUED)

After the System Power switch is pressed and motion of components has appeared to stop, additional movement can occur.

- SYSTEM POWER ON and OFF/STOP SWITCH (RED) - Must be in the ON position for any function of the pack mechanism to operate. Side door must be closed.
 - a. PULL for ON position.
 - b. PUSH for OFF/STOP position.

NOTICE

The packer panel can be stopped at any position by pushing switch to OFF/STOP position.

- 2. PACKER EXTEND BUTTON (GREEN) A green light that illuminates to indicate the packer panel is extending. Light will go off when panel is stopped.
- 3. PACKER RETRACT BUTTON (YELLOW) A yellow light that illuminates to indicate the packer panel is retracting toward the front head. Light will go off when panel is fully back to front head.
- 4. HYDRAULIC PUMP LIGHT (RED) A red light that illuminates to indicate the hydraulic pump has been turned on. Light will go off when pump is disengaged.

 CHANGE FILTER or FILTER BYPASS LIGHT (RED)

 A red light that flashes to indicate the filter is in or has been in bypass and the element needs to be changed as soon as possible. Each light flash is for each hour of operation with the filter in bypass.

NOTICE

When the transmission overheats, the hydraulic pump will automatically shut down for approximately 3 minutes. It is recommended that the transmission be placed in neutral and engine sped up to help cool the transmission.

- 6. TRANSMISSION TEMPERATURE LIGHT (RED) (OPTION) - A red light that flashes to indicate the transmission fluid temperature has exceeded a safe operating range. Light will go off when transmission is cooled down.
- 7. LIFT ARM EXTENDED LIGHT (RED) A red light that illuminates to indicate the lift is extended and not in the grabbers open or transit position. Light will go off when lift is in the transit (stowed) position.
- 8. TAILGATE OPEN LIGHT (RED) A red light that illuminates to indicate the tailgate has been opened. Light will go off when tailgate is fully closed.
- ALARM Sounds when tailgate or body is opened or raised, the lift is extended, when switching between Auto and Manual Pack Modes 69 or Auto and Manual Lift Modes 69, when various other conditions occur, or a fault condition occurs. Refer to Diagnostic Fault Codes 129 and the Service Manual, "Body Controller Software" section.

IN-CAB MAIN CONTROL PANEL (CONTINUED)

- 10.BODY RAISED LIGHT (RED) A red light that illuminates to indicate the body is raised off the chassis rail (Service Hoist and Service Lift Models). Light will go off when body is completely down on the chassis rail.
- 11.SIDE DOOR OPEN LIGHT (RED) An optional red light that illuminates to indicate the side door is open or not fully closed. Light will go off when door is fully closed.
- 12.HOPPER COVER LIGHT (RED) A optional red light that illuminates to indicate the hopper cover (top door) is closed over the hopper area. Light will go off when hopper cover is open and up against the body wall.
- 13.BODY RAISE/LOWER SWITCH Controls raising and lower the body (Service Hoist and Service Lift models).
 - a. PUSH to RAISE position to RAISE.
 - b. PULL to LOWER position to LOWER.

- 14.TAILGATE RAISE/LOWER SWITCH Controls raising and lowering of the tailgate.
 - a. PUSH to RAISE position to RAISE.
 - b. PULL to LOWER position to LOWER.
- 15.TAILGATE LOCK/UNLOCK TOGGLE SWITCH -Controls locking and unlocking of tailgate.
 - a. PUSH to UNLOCK position to UNLOCK.
 - b. PULL to LOCK position to LOCK.
- 16.HOPPER COVER SWITCH (OPTION) Controls opening and closing of the hopper cover (top door).
 - a. PUSH to CLOSE position to CLOSE.
 - b. PULL to OPEN position to OPEN.
- 17.HOPPER FLOOD LIGHT SWITCH An optional ON/ OFF switch that when turned on, illuminates the hopper area. Use in minimal light conditions or darkness. Turn OFF when not needed.
- 18.LIFT FLOOD LIGHT SWITCH An optional ON/OFF switch that when turned on, illuminates the area where the lift operates. Use in minimal light conditions or darkness. Turn OFF when not needed.
- 19.AUXILIARY FLOOD LIGHT SWITCH An optional ON/OFF switch that may be used for other optional functions.
- 20.REAR STROBE LIGHT SWITCH An optional ON/ OFF switch that when turned on operates the rear strobe light. Turn OFF when not needed.

PYTHON LIFT JOYSTICK CONTROLS

The joystick controls all of the lift functions and has five (5) push buttons to control the grabbers, pump, and packer panel. They are identified as follows.

A. Joystick Movements

The joystick can be moved forward, backward, sideways and at an angle for the different functions. See the figure the right for the different movements and the functions they control.

- 1. LIFT RAISE Pull and hold joystick to raise the lift. Release the joystick to stop the movement of the lift.
- LIFT LOWER Push and hold joystick to lower the lift. Release the joystick to stop the movement of the lift.
- 3. LIFT RETRACT Move joystick to the left and hold to retract the lift. Release the joystick to stop the movement of the lift.
- 4. LIFT EXTEND Move joystick to the right and hold to extend the lift. Release the joystick to stop the movement of the lift.
- 5. DUMP Pull joystick down and to the left and hold for lift to move in and up to dump the container. Release the joystick to stop the movement of the lift.
- 6. UNDUMP Push joystick up and to the right and hold for lift to move out and down to place container on the ground.

 Trigger (Dead Man) - This optional trigger on the joystick is used as a dead man switch only. When equipped, it must be depressed when operating the Joystick Lift control functions (raise, lower, in, out functions). If it is released, the joystick lift functions will not operate.



Figure 42. Python Lift Joystick Movements/Functions

PYTHON LIFT JOYSTICK CONTROLS

B.5 Push-Button Controls

The joystick has 5 push-buttons on the handle that control the pump, grabbers, and packer panel extend/ retract functions. See the figure below for the different functions of the push-buttons.



NOTICE

The power ON/OFF knob (red) must be pulled to the ON position and the pump switch depressed for the packer to work.

- 1. PUMP ON (RED) DEPRESS and RELEASE button to activate the Hydraulic Pump. Depress button to turn Pump OFF.
- 2. PACKER EXTEND (GREEN) DEPRESS and RELEASE button and the Packer Panel will go through one complete packing cycle.
- 3. PACKER RETRACT (YELLOW) DEPRESS and RELEASE button and the Packer Panel will retract to the front of the body.
- 4. GRABBER OPEN (GRAY) DEPRESS and HOLD button, when the grabbers get to the desired open position, release the button.
- 5. GRABBER CLOSE (GRAY) DEPRESS and HOLD button until grabbers are fully closed around the container. Release button.

To toggle the control between Auto and Manual Lift Modes with the System Power (E-Stop) button ON, PRESS and HOLD the Grabber Open and Grabber Close buttons simultaneously until the in cab alarm stops sounding.

To toggle the control between Auto and Manual Pack Modes with the System Power (E-Stop) button ON, PRESS and HOLD the Packer Extend and Retract buttons simultaneously until the in cab alarm stops sounding.

For more information on Auto Modes, see Features 6th.

PYTHON LIFT JOYSTICK CONTROLS

See the figure below for the Python Lift joystick decal.



SERVICE HOIST

The Service Hoist model has an outside control assembly that controls the raising and lowering of the body for service and maintenance operations by service personnel only.

The control is part of the service hoist pump. See the figure to the right and refer to **Propping the Body (Service Hoist Units)** at in the next section for Service Hoist and Factory Body Props operation procedures and additional safety notices.

Interconnected body props are installed on the unit. Both props MUST be used.

A DANGER

Keep all parts of your body out from underneath the unit's body and away from the cylinders when raising or lowering the body. Serious injury or death will occur if the unit's body suddenly lowers and traps a part of your body. Always use the body props when you must leave the body raised for maintenance or cleaning operations.

The unit may roll when you raise the body on unstable or uneven ground and cause serious injury or death to you or bystanders. Do not prop the body while the unit is on unstable or uneven ground. Clear the area of all people not necessary for this procedure and set the unit on stable and even ground before you start this procedure. Make sure all tire pressures are correct.



Figure 45. Typical Service Hoist Controls Location

NOTES:

SECTION 6 DAILY CHECKLIST

Copyright 2017, Heil Environmental Printed in U.S.A.

DAILY CHECKLIST

Make sure you perform a daily check of the unit. Make copies of the **Refuse Vehicle Daily Inspection** and the next several pages to have the Operator mark completed items before each route. Many checks in the Daily Checklist are maintenance related, such as checking tire pressures and hoses for wear and damage.

Refer to the Daily Checklist Maintenance Items Chart below for items to check and the required action.

DAILY CHECKLIST MAINTENANCE ITEMS				
Item	Required Action			
Low air pressure in tires	Inflate the tire to the correct air pressure given on the tire			
Worn tire	Replace when the wear is greater than allowed by law or before the tread is no longer visible			
Damaged tire	Replace immediately BEFORE going on route.			
Hydraulic pump leaks	Determine the cause of the leak and repair immediately.			
Damaged hydraulic pump	Repair or replace IMMEDIATELY			
Loose or missing hardware for the hydraulic pump	Tighten loose hardware Replace missing hardware immediately			
Damaged decal or decal not readable	Replace decal immediately			
Low level of hydraulic oil	Fill the hydraulic oil tank immediately			
Worn or damaged hoses	Replace immediately			
Leaks at cylinders, hoses or fittings.	Tighten loose connection			
Loose or missing hardware	Tighten loose connections Replace missing hardware			
Worn fiber guards	Replace hoses/fittings as necessary Install new fiber guard on new hoses			
Worn or damaged tailgate lock components	Replace worn or damaged components			
Loose or missing tailgate lock hardware	Tighten loose hardware Replace missing hardware			
Damaged tailgate seal	Replace seal			

DAILY CHECKLIST MAINTENANCE ITEMS				
Item	Required Action			
Body structure has loose or missing hardware	Tighten loose hardware Replace missing hardware			
Body structure has cracked weld joints	Repair immediately			
Body mounting brackets have loose hardware, damaged hardware or cracked welds	Tighten loose hardware Replace missing hardware Repair cracked welds			
Air regulator (typically located at front of body)	90 PSI			



REFUSE VEHICLE	DATE:	/	/
DAILY INSPECTION			

UNIT NO. _

Enter one of the following codes in the Inspection Results Code column:

Use a $\sqrt{}$ to indicate inspected and no repair, service or adjustment is necessary.

Use an **R** to indicate repair, service or adjustment is necessary. Use an **N** to indicate vehicle not equipped.

FOLLOW ALL APPLICABLE LOCK-OUT / TAG-OUT PROCEDURES

Printed Name of Operator:

I certify with the signature that follows that I performed a complete inspection in accordance with the following check list on the date given above.

Signature of Operator:

Refer to **Preventative Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Chart Maintenance Ch**

Copyright 2017, Heil Environmental Printed in U.S.A.

CHECKS AND INSPECTIONS

INSPECT PER APPLICABLE MANUFACTURER MANUAL

INSPECTION RESULTS CODE (√/R/N)

Wheels and Tires

Tractor and Chassis Electrical

Chassis

Engine & Transmission & Fluid Levels

Tractor, 5th Wheel and Chassis Lubrication

REFUSE COLLECTION SYSTEMS AND COMPONENTS

CAB OUTSIDE AREA

Check air pressure of tire. Add air if air pressure lower than recommended on the tire before going on route

Check wear of tire tread. Replace tire worn below tire manufacturer's recommendation or state requirement before going on route

Check tires for damage. Replace any damaged tire before going on route

Inspect pump for leaks

Inspect pump for damage or loose hardware

Decals on bumper for damage and readability

Inspect unit for refuse on or about the engine or exhaust components. Remove all refuse to prevent a fire

BODY AND CHASSIS CURB SIDE INSPECTION

Inspect level of hydraulic oil if tank is mounted on curb side. It must be full. Add recommended oil as necessary

Inspect loader hydraulics for

Cylinder, hoses and fittings for leaks

CHECKS AND INSPECTIONS

Hoses for wear and damage

Cylinders for damage

Loose or missing mounting hardware

Worn fiber guards – replace hoses/fittings as necessary – MAKE SURE TO INSTALL FIBER GUARD ON NEW HOSE TO PREVENT HYDRAULIC LEAKS REACHING ENGINE SURFACES WHICH CAN CREATE A FIRE HAZARD

Inspect decals on body prop for damage and readability

Inspect body structure for damage, loose or missing nuts and bolts and for cracked welds and metal

Inspect body mounting brackets for cracked welds, missing bolts or nuts or movement

Inspect decals on curb side body for damage and readability

Check air pressure of tires. Add air to any tire with air pressure lower than recommended before going on route

Check wear of tire treads. Replace any tire worn below tire manufacturer's recommendation or state requirement before going on route

Check tires for damage. Replace any damaged tire before going on route

Inspect tailgate raise components

Cylinder, hoses and fittings for leaks

Hoses for wear and damage

Cylinder for damage

Loose or missing mounting hardware

Inspect tailgate lock components Latch components for wear or damage

Loose or missing mounting hardware

INSPECTION RESULTS CODE

(√/R/N)

CHECKS AND INSPECTIONS	INSPECTION RESULTS CODE (√/R/N)
Tailgate is locked	
TAILGATE	
Inspect decals on tailgate and underride bumper for damage and readability	
Inspect tailgate seal for visible damage	
Inspect underride bumper for damage and loose components	
BODY AND CHASSIS STREET SIDE INSPECTION	
Tailgate is locked	
Inspect tailgate lock components	
Latch components for wear and damage	
Loose or missing mounting hardware	
Inspect tailgate raise components	
Cylinder, hoses and fittings for leaks	
Hoses for wear and damage	
Cylinder for damage	
Loose or missing mounting hardware	
Check air pressure of tires. Add air to any tire with air pressure lower than recommended before going on route	
Check wear of tire treads. Replace any tire worn below tire manufacturer's recommendation or state requirements before going on route	
Check tires for damage. Replace any damaged tire before going on route	
Inspect all decals on curb side body for damage and readability	
Inspect body structure for damage, loose or missing nuts and bolts and for cracked welds	

DuraPack[®] Python[®]

CHECKS AND INSPECTIONS

INSPECTION **RESULTS CODE** (√/R/N)

Inspect body mounting brackets for cracked weld, missing bolts or nuts or movement Inspect decals on body prop for damage and readability Inspect level of hydraulic oil if tank is mounted on streetside. It must be full. Add recommended oil as necessary If equipped, the hopper cover is DOWN Battery disconnect switch is turned to OFF then: Check wiring and battery cables from the battery box to the engine starter for wear and other damage. IMMEDIATELY REPLACE WORN OR DAMAGED WIRING Check wiring and cables for loose connections. IMMEDIATELY TIGHTEN LOOSE CONNECTIONS OPERATION OF UNIT - Skip this section if the unit will not be operated today Close the air tank drain valve Turn battery disconnect to ON Apply parking brake Make sure the starter interlock operates - make sure unit will not start in gear Start the engine. Indicator lights and gauges show normal operation of engine Make sure the parking brake does not allow the vehicle to move forward or reverse at idle Make sure the throttle advance (if equipped) operates only in neutral Make sure all cab, body and tailgate lights operate Make sure the backup alarm and light operate Make sure all people not necessary and any hazards are clear of the area and then: If equipped, engage the PTO Pull the System Power knob UP - the switch's red light is ON and the PUMP ON light is ON

INSPECTION RESULTS CODE (√/R/N)

Push the System Power knob DOWN – the switch's red light is OFF and the PUMP ON light is OFF

Pull the System Power knob UP – the switch's red light is ON and the PUMP ON light is ON

The FILTER CHANGE light is OFF. If not, and the filter was not changed before starting the unit, report this to your supervisor immediately. DO NOT go on route until the unit is repaired if the filter was not changed

Operate the packer in the auto mode - the packer does one extend and retract cycle

Operate the packer in the manual mode - manually extend and retract the packer

Start a packer extend operation then press the Retract button. The packer should stop extending and move towards the cab.

Start a packer retract operation then press the Extend button. The packer should stop retracting and move towards the body.

The TRANS TEMP light is OFF. If not, report this to your supervisor immediately. Do not go on route until the unit is repaired

Operate all four single functions of the lift with the standard Python joystick controls:

OUT, IN, RAISE, LOWER, DUMP and UNDUMP

Do a Coordinated Lift cycle with the standard Python joystick controls.

If the body has refuse:

Raise the body slightly – the BODY T/G UP light and alarm are ON

Lower the body completely until it rests on the chassis

The BODY T/G UP light and alarm are OFF

If the body does not have refuse, use the in-cab controls and:

Raise the body

The BODY T/G UP light and alarm are ON

Make sure the body props rotate fully down, then store the body props

CHECKS AND INSPECTIONS	INSPECTION RESULTS CODE (√/R/N)
Lower the body completely	
The BODY T/G UP light and alarm are OFF	
Open the tailgate	
The BODY T/G UP light and alarm are ON	
Set the tailgate props	
Inspect the tailgate seal for damage	
Store the tailgate props and raise the tailgate completely	
Close the tailgate	
The BODY T/G UP light and alarm are OFF	
Make sure the tailgate flag is DOWN (if equipped).	
Move the lift arm to the TRANSIT position – lift arm is stowed and the grabber is fully OPEN and against the unit OR move the lift arm to the alternate position – lift arm is IN and the grabber is in the hopper	
Keep the engine running and continue the inspection	
IN-CAB INSPECTION	
Inspect all in-cab decals for damage and readability	
Do one automatic packer cycle	
Make sure the following control panel indicator lights are OFF:	
Body T/G UP	
TRANS TEMP	
FILTER CHANGE	

DuraPack[®] Python[®]

CHECKS AND INSPECTIONS

PUMP ON light is OFF – if it is ON, push the System Power knob DOWN

If equipped, check the operation of each camera

FINAL INSPECTION

While you walk completely around the vehicle, look for:

Fluid leaks

Cracked or damaged welds and metal

Loose or missing bolts, nuts and clamps

INSPECTION RESULTS CODE

(√/R/N)

NOTES:

SECTION 5 BODY AND TAILGATE PROPS

Copyright 2017, Heil Environmental Printed in U.S.A.

PREVIEW

Read this section to learn about:

- Using the body props
- Using the tailgate props

PROPPING THE BODY OF A SERVICE HOIST UNIT

Operators **MUST KNOW** how to **SAFELY** prop up the unit's body. You may need to prop the body up when you clean the inside of the body or for maintenance or repair procedures.

Observe and obey the following DANGER and WARNING notices while you prop the body with the factory body props.

Keep all parts of your body out from underneath the unit's body and away from the cylinders when raising or lowering the body. Serious injury or death will occur if the unit's body suddenly lowers and traps a part of your body.

The unit may roll when you raise the body on unstable or uneven ground and cause serious injury or death to you or bystanders. Do not prop the body while the unit is on unstable or uneven ground. Clear the area of all people not necessary for this procedure and set the unit on stable and even ground before you start this procedure. Make sure all tire pressures are correct.

Interconnected body props are installed on the unit. Both props MUST be used.

Never drive the unit with the body propped.

NOTICE

Empty body of all refuse before using body props.

NOTICE

Units manufactured after April 2009 have the manual override valve. If you have not experienced problems with the service hoist, you may not need the override valve. If you have experienced problems with the service hoist, contact your Heil dealer or Heil.

PROPPING THE BODY OF A SERVICE HOIST UNIT (CONTINUED)

Factory Body Props

The factory-supplied body props are located on both sides under the body and forward of the rear wheels. Carefully follow the body propping procedures below.

☑ Follow These Steps:

Raising the Body

- 1. Empty body of all refuse.
- 2. Make sure that body is on firm, level ground with the Parking Brake engaged and holding and place chocks on the wheels.
- CLOSE the manual override valve on the power unit – PUSH the knob IN and turn it CLOCKWISE.
- 4. Lock-Out/Tag-Out 55 the unit.
- 5. Remove the bolts and springs from the chassis mounting brackets. See the figure below.



Figure 46. Removing Bolts and Springs from Chassis Mounting Brackets

Raising the Body (Continued)

- 1. If equipped with quick disconnects, uncouple prior to raising the body.
- 2. Make sure there is adequate slack in hoses that do not have disconnects. If there is not adequate slack in hoses that do not have disconnects, remove those hose clamps.
- 3. Observe and obey the DANGER labels for an elevated chassis.
- 9. PRESS and HOLD the UP button to RAISE the body.
- 10.RELEASE the UP button when the body is at the height you want.
- 11.Release the prop handles and LOWER the body props, then PRESS the DOWN button to lower the body onto the lugs. See the figure below.



PROPPING THE BODY OF A SERVICE HOIST UNIT (CONTINUED)

Raising the Body (Continued)

- 12.NEVER open the override valve when the body is elevated.
- 13. Perform the maintenance or service procedures.

Lowering the Body

- 1. PRESS the UP button until the body is not resting on the body props.
- 2. RAISE the body props and store the handles.
- 3. Press and hold the DOWN button to lower the body.
- 4. Release the DOWN button when the body is completely down and resting on the chassis.
- 5. OPEN the manual override valve PUSH the knob IN and turn it COUNTER-CLOCKWISE.
- Make sure the manual override valve is open PUSH the service hoist UP button. The body will not raise.
- If any hose clamps were removed to create adequate slack during body raise, then re-install those hose clamps.
- 8. If equipped with quick disconnects, reattach the quick disconnects.
- 9. Install the bolts and springs to the chassis mounting brackets.

NOTES:

PROPPING THE BODY OF A SERVICE LIFT (SERVICEABLE EJECT) UNIT

Operators **MUST KNOW** how to **SAFELY** prop up the unit's body. You may need to prop the body up when you clean the inside of the body or for maintenance or repair procedures.

Observe and obey the following DANGER and WARNING notices while you use a service lift to raise the body.

Keep all parts of your body out from underneath the unit's body and away from the cylinders when raising or lowering the body. Serious injury or death will occur if the unit's body suddenly lowers and traps a part of your body.

A DANGER

The unit may roll when you raise the body on unstable or uneven ground and cause serious injury or death to you or bystanders. Do not prop the body while the unit is on unstable or uneven ground. Clear the area of all people not necessary for this procedure and set the unit on stable and even ground before you start this procedure. Make sure all tire pressures are correct.

A DANGER

All cranes, chains and cables used MUST be of adequate lift rating.

Never drive the unit with the body propped.

NOTICE

Empty body of all refuse before raising the body with a service lift.

PROPPING THE BODY OF A SERVICE LIFT (SERVICEABLE EJECT) UNIT (CONTINUED)

Factory Body Props

The factory-supplied body props are located on both sides under the body and forward of the rear wheels. Carefully follow the body propping procedures below.

☑ Follow These Steps:

Raising the Body

- 1. Empty body of all refuse.
- 2. Make sure that body is on firm, level ground with the Parking Brake engaged and holding and place chocks on the wheels.
- 3. Lock-Out/Tag-Out 55 the unit.
- 4. Remove the bolts and springs from the chassis mounting brackets. See the figure below.



Figure 48. Removing Bolts and Springs from Chassis Mounting Brackets

Raising the Body (Continued)

- 5. Disconnect all wire harnesses, hydraulic hoses, and air lines that would prevent the body from raising or be damaged by the body raising.
- 6. Observe and obey the DANGER labels for an elevated chassis.
- Connect a chain or cable sling with hooks from the front body chain hook lugs to an overhead crane, truck crane or other lifting device having adequate capacity to safely lift the body. See the figure below.



Figure 49. Front Body Chain Hook Lugs

8. Using the lifting device, slowly lift the body in a controlled manner high enough to lower the factory body props.

PROPPING THE BODY OF A SERVICE LIFT (SERVICEABLE EJECT) UNIT (CONTINUED)

Raising the Body (Continued)

9. RELEASE the prop handles and LOWER the body props. See the figure below.



Figure 50. Release and Lower Factory Body Props

10. Using the lifting device, slowly lower the body in a controlled manner until the body is resting on the prop stands. See the figure below.



Figure 51. Lower Body onto Factory Body Props

11.Perform the maintenance or service procedures.

Lowering the Body

- 1. Observe and obey the DANGER labels for an elevated chassis.
- 2. Connect a chain or cable sling with hooks from the front body chain hook lugs (each side) to an overhead crane, truck crane or other lifting device having adequate capacity to safely lift the body.
- 3. Using the lifting device, slowly lift the body in a controlled manner high enough to raise (store) the factory body props. See the figure to the left.
- 4. Using the lifting device, slowly lower the body in a controlled manner until it is resting on the chassis frame.
- 5. With the body completely down and resting on the chassis, remove the cable or chain.
- 6. Reconnect all wire harnesses, hydraulic hoses, and air lines that were disconnected.
- 7. Install the bolts and springs to the chassis mounting brackets.

PROPPING THE BODY

There are no body props on NYC Half/Pack units since they are Eject units.

PROPPING THE TAILGATE

YOU MUST prop the tailgate when you open it for service or maintenance. Use the instructions that follow and prop the tailgate with either the factory-installed tailgate props or a tailgate prop built specifically for your unit.

Observe and obey the following DANGER and WARNING notices while you prop the body with either the factory body props or with alternate props.

A DANGER

A tailgate is dangerous while you raise or lower it. A prop may fail and cause the tailgate to close suddenly which can result in serious injury or death if you become trapped between the tailgate and the body. Do not walk under or go between the body and the tailgate when the tailgate is in motion, while you prop the tailgate or while the tailgate is propped.

Factory Tailgate Props

YOU MUST USE BOTH of the two support props at the rear of each unit whenever you open the tailgate for service or maintenance.

Refer to the figure on the next page and carefully follow the tailgate propping procedures below.

☑ Follow These Steps:

A. How to Use the Tailgate Props

- 1. Set unit on flat, stable ground, apply the parking brake, and chock the wheels.
- 2. Make sure the area around the tailgate is clear of all people.
- 3. UNLOCK the tailgate. Make sure the tailgate unlock flags are down (if equipped).
- 4. Use the tailgate raise lever or rocker switch in the cab (if equipped) to RAISE the tailgate enough to RELEASE and ROTATE the props so that you can SECURE each prop on its prop pin on each side of the tailgate.
- 5. LOWER the tailgate until you can SECURE each PROP on its pin.
- 6. Turn OFF the engine and REMOVE the ignition key.
- 7. Put the unit in the Lock-Out/Tag-Out mode. Refer to Lock-Out/Tag-Out Procedure

PROPPING THE TAILGATE (CONTINUED)

B. How to Store the Tailgate Props

- 1. When you finish using the props, take the unit out of the Lock-Out/Tag-Out mode, insert the ignition key, and start the engine.
- 2. RAISE the tailgate enough so that you can REMOVE each prop bar from its pin, then ROTATE each prop so that you can put the props in the stored position.
- 3. SECURE each prop with a pin.
- 4. LOWER the tailgate until it is completely CLOSED.
- 5. LOCK the tailgate.



SECTION 7 BEFORE GOING ON ROUTE

Copyright 2017, Heil Environmental Printed in U.S.A.

PREVIEW

Read this section to learn proper procedures for:

- Checking the unit each day
- Starting the unit in cold weather
- Setting the unit up for the route
- Removing power to the unit during periods of not using the unit.

BATTERY DISCONNECT SWITCH

The battery box is typically located on the streetside of the chassis frame near the front of the body, however it can be mounted at a different location on different chassis. Become familiar with the location of the battery box and battery disconnect switch on your unit.

- 1. You must turn the battery disconnect switch to the OFF position whenever the unit is shut off for any length of time especially when the unit will be left unattended.
- 2. You must turn the battery disconnect switch to the ON position whenever you will use the unit.
- 3. You must check the position of the battery disconnect switch as part of the daily inspection.

NOTICE

Battery cables must be securely anchored and not rubbing other equipment. Cable insulation must be free of damage and abrasion. Inspect weekly.

NOTICE

Always disconnect the battery before welding on the chassis or body.

DAILY CHECKLIST

See the **Daily Check section** 73 for the daily checks and procedures checklist. Make a copy of the check list.

A WARNING

A unit that needs service or repair can malfunction and create a dangerous condition. A part failure during operation can cause serious injury or death to a person or damage to the unit. Repair or replace any failed or defective part immediately.

BEFORE STARTING A ROUTE

Before you start a route, do the following:

- □ Perform an inspection of the unit with the **Daily** Checklist 73.
- □ Check the Hydraulic Oil Tank.
- □ Cycle all Hydraulic Functions.
- $\hfill\square$ If equipped, close the **Side Access Door**.
- □ If equipped, close the Sliding Top Door (Hopper Cover).
- □ Check the "In-transit" Settings.

Use the Daily Checklist to Inspect the Unit

It is the operator's responsibility to do a visual inspection of the unit and make sure the unit is in good operating condition before you start a route.

The requirements for the daily checks are given in the **Daily Checklist section** 73. Make sure you complete the inspections on the checklist and you make all entries, including your signature.

COLD WEATHER WARMUP PROCEDURE

When ambient air temperature is cold (below 0 degrees F), it is necessary to warm up the unit's hydraulic oil before you start your daily route operation or to check the oil level. The hydraulic oil is sufficiently warmed when the temperature is between 120° and 160° F.

A WARNING

Moving parts on the unit are dangerous. Serious injury or death can occur if a person is struck by the equipment. Clear all people from the area before you operate the unit

Follow the steps below to warm up the hydraulic oil.

- 1. START the TRUCK and let the engine idle.
- 2. APPLY the PARKING BRAKE and make sure it holds.
- 3. ENGAGE the HYDRAULIC PUMP for approximately five minutes.
- 4. MAKE SURE the AREA IS CLEAR of all unnecessary people BEFORE you operate the controls.
- 5. OPERATE the PACKER EXTEND and PACKER RETRACT functions through ten (10) cycles while the engine idles. See the Operator's Manual for operation instructions.
- 6. Make sure the oil temperature on the site gauge is between 120° and 160°F. If not, repeat step 5.
- 7. Check for fluid leaks. Repair if necessary.

PREPARING THE UNIT TO CHECK THE HYDRAULIC OIL LEVEL

Before checking the oil level or adding oil, make sure the oil is warmed up and the unit is in the following position with all cylinders collapsed:

- Truck on level ground
- Tailgate and Body fully down and locked
- Packer Panel in the in-transit position with all cylinders retracted
- Lift Arm (if equipped) is fully retracted

CHECK HYDRAULIC OIL LEVEL

Check the hydraulic oil level (after warming up the oil) daily or every eight (8) hours, whichever comes first. Fill as necessary.

CYCLE ALL HYDRAULIC FUNCTIONS

☑ Follow These Steps:

- Operate the lift arm, grabbers, top door (if equipped), packing panel, body and tailgate functions two or three times each. See Section 4 59 for proper operation of controls.
- 2. Put the unit back in the position described above and check the oil level again.

3. Add oil if necessary. See the "Recommended Hydraulic Oil" chart below. Refer to the Service Manual for instructions for filling the oil tank.

RECOMMENDED HYDRAULIC OIL

The following oils by brand name are approved for use in the hydraulic system on this equipment and considered to be all-temperature hydraulic fluids:

- Shell Tellus T32
- Mobil DTE 13M
- Texaco Rando HDZ 32

NOTE: Cold weather operation requires special oil considerations. Viscosity should not exceed 7500 SSU at lowest startup temperature. Continuous operation should range between 40–1000 SSU for all temperature ranges.

NOTICE

Contamination is a hydraulic system's worst enemy. DO NOT let dirt enter the system. Use a clean rag and remove dirt or other contamination around any system component before you disconnect or remove it. While you fill the reservoir, filter the oil through a 200 mesh (or finer) screen. NEVER use a cloth to filter the oil.

HYDRAULIC OIL TANK WITH SIGHT GAUGE




CHECK THE TRAVELING OR "IN-TRANSIT" POSITION

When you travel to and from the landfill or transfer station, make sure the unit is in the In-Transit Position as follows:

- The Body is fully LOWERED.
- The Tailgate is DOWN and LOCKED.
- The Lift Arm is in a transit position:
 - o The lift arm is fully stowed
 - The grabber arm assembly is against the chassis and the grabbers are fully open
- The Top Door (Hopper Cover) is:
 - For a unit before it is on-route CLOSED
 - o For an on-route unit OPEN
- The Packer Panel is:
 - For an empty unit, it is at the front of hopper.
 - For a unit with refuse in the body, it is up tight against refuse.
- The PTO or Pump Switch is OFF.
- The Mirrors are properly adjusted and clean.
- The Side Access Door and Sump Doors are CLOSED and LATCHED.
- ALL outside lights operate properly.
- The street side driver's station is used for traveling.

Use of Curbside Drive

If equipped, drive from the curbside driver position **ONLY** on the collection route. **DO NOT** use this station during travel to and from a route, landfill, or transfer station.

NOTES:

SECTION 8 ON-ROUTE OPERATION PROCEDURES

Copyright 2017, Heil Environmental Printed in U.S.A.

PREVIEW

Read this section to learn about:

- Setting up the unit for a route
- Loading refuse manually with the lift arm
- Packing the load
- · Packing on-the-move
- Washout system
- Setting up the unit for the landfill or transfer station.

DRIVING TO PICK-UP LOCATIONS

Whenever you drive to and from a route, along the route, to the landfill, etc., make sure the unit is set up in the **In-Transit Position**:

- The Body is fully LOWERED.
- The Tailgate is DOWN and LOCKED.
- The Lift Arm is in a transit position:
 - The lift arm is fully stowed
 - The grabber arm assembly is against the chassis and the grabbers are fully open
- The Top Door (Hopper Cover) is:
 - For a unit before it is on-route CLOSED
 - For an on-route unit OPEN
- The Packer Panel is:
 - For an empty unit, it is at the front of hopper.
 - For a unit with refuse in the body, it is up tight against refuse.
- The PTO or Pump Switch is OFF.
- The Mirrors are properly adjusted and clean.
- The Side Access Door and Sump Doors are CLOSED and LATCHED.
- ALL outside lights operate properly.
- The street side driver's station is used for traveling.

Use of Curbside Drive

If equipped, drive from the curbside driver position **ONLY** on the collection route. **DO NOT** use this station during travel to and from a route, landfill, or transfer station.

LIFTING AND LOADING REFUSE WITH THE PYTHON $^{\ensuremath{\mathbb{R}}}$ LIFT ARM

Use the following procedures at each stop along the route to load refuse into the unit. Observe all DANGER and WARNING hazard alerts.

NOTICE

If local rules and laws require more clearance, you must follow them.

- 1. Move the unit to a position that is best to load the refuse with the lift arm. Practice this maneuver for best results.
- 2. ADJUST the container spot mirror for BEST overhead vision of the hopper while you raise container.
- 3. PULL the SYSTEM POWER switch UP (and engage the PTO if equipped). The PUMP ON light should be ON.

NOTICE

If the engine RPMs go above 900, both pumps will be shut off and the lift will not operate.

4. The Operator's foot is on the service brake and the engine RPMs are at or below 900.

Moving equipment can be dangerous. Serious injury or death may occur if a person is in the wrong area or is not attentive to the operations. Clear the area of all unnecessary people before you operate the controls.

- 5. Make sure the loading area is clear of all unnecessary people.
- 6. Make sure the packer is in the Auto Pack mode 6.
- 7. If equipped, the hopper cover is OPEN. You can damage the unit if you try to load refuse if the hopper cover is CLOSED.

LIFTING AND LOADING REFUSE WITH THE PYTHON[®] LIFT ARM (CONTINUED)

Auto-Lift Mode

A DANGER

Contact of the unit with overhead electric lines is dangerous. Serious injury or death may occur. Make sure there is adequate overhead clearance before you raise the container. Refer to **Tables 1 and 2. Overhead Clearances** 29. If the unit does make contact with overhead electric lines do not touch any metal in the cab. Stay in the unit until help arrives.

NOTICE

If local rules and laws require more clearance, you must follow them.

All units are equipped with the Auto-Lift feature. This feature allows the operator to partially automate the lifting, dumping and returning the refuse container to the ground.

<u>Auto-Lift</u>

- 1. Toggle ON/OFF by holding grip and release buttons simultaneously for five (5) seconds (until the in cab alarm stops sounding).
- 2. Closing grabbers will initiate Auto-Lift sequence. Operator must hold grabber closed button to continue cycle.
- 3. Container will raise and retract automatically to the dump position.
- 4. Operator manually replaces cart to desired position on the ground.
- 5. Pressing and holding grabber release (open) button will return lift to stowed position.
- 6. Go to the next stop on the route.

LIFTING AND LOADING REFUSE WITH THE PYTHON[®] LIFT ARM (CONTINUED)

Manual Lift Mode

A DANGER

Contact of the unit with overhead electric lines is dangerous. Serious injury or death may occur. Make sure there is adequate overhead clearance before you raise the container. Refer to **Tables 1 and 2. Overhead Clearances** 29. If the unit does make contact with overhead electric lines do not touch any metal in the cab. Stay in the unit until help arrives.

NOTICE

If local rules and laws require more clearance, you must follow them.

1. Command Extend with the joystick to make the lift extend towards the container. During reach the lift will retain its stowed height in close to the truck however reaching out farther from the unit requires the operator to control the lift height simultaneously while reaching.

NOTICE

Make sure the container is in the center of the grabbers. DO NOT use the tips of the grabbers to squeeze and lift the container.

- 2. Command Grab when the container is in the position. Grabbing the container lower in the strike zone will position the container farther into the hopper during full dump.
- 3. Command Dump by moving the joystick into the dump (7:30) position. The dump position is "sweet spot" that splits the in and up functions to get a perfect dump motion. Finding the dump position with the joystick usually requires practice to obtain a consistent and smooth dump motion. Amateur operators should error to the in position of the joystick rather than up while dumping. Erring to the up position will cause premature dumping and result in trash spilled on the ground.
- 4. Container Placement Command down by moving the joystick forward. When the container is at the appropriate level, release and stow the grabbers. Note: If it is necessary to return the container to it's original position, beginner operators should completely lower the container first and then reach out as required. Only experienced operators should attempt to reach out while lowering the lift simultaneously.
- 5. Go to the next stop on the route.

LIFTING AND LOADING REFUSE WITH THE PYTHON[®] LIFT ARM (CONTINUED)

NOTES:

Operator Proficiency

While learning to operate the Python, the operator should not concentrate on speed (except dumping) but should focus on making precision movements with the lift. Exception to slow operation should be taken during the dump function. The operator must be aggressive while commanding the dump function to obtain a smooth dump motion without spilling trash on the ground. Once precision movements are mastered, lift speed will naturally occur. The joystick should be considered as an extension of the operator's body, as the precision movements are mastered and veteran operational status and experience is obtained.

COMPACTING THE LOAD

Loads can be compacted automatically or manually. In addition to the auto-pack mode during loading, you can pack the refuse manually any time after loading the refuse in the hopper. You can use the in-cab controls for the packer panel to compact the load again with a manual cycle.

Many factors affect how often you need to compact the load, including the operator's experience.

Select-O-Pack™

Select-O-Pack is a standard feature on all Cortex Controller[™] controlled Heil Automated Side Loaders. This feature automatically cycles the Auto-Pack after a predetermined number of lift cycles.

Refer to **Select-O-Pack** in **Features** 6 for instructions on setting the Select-O-Pack feature.

Packing Near Full Load

When the body is near a full load, the packing cylinder will not extend fully before returning to the front of the hopper.

Packing On-The-Move

Heil DuraPack[®] Python[®] units can pack on-the-move. This means you can operate the packing mechanism while the vehicle is moving, as well as when it is stationary. The default mode of the body pump is the AUTO PACK mode. This allows for continuous packing while the SYSTEM POWER switch is set to ON (and if equipped, the PTO is engaged), the pump is ON and the unit's engine is running.

You can pack-on-the-move when the Cortex Controller determines that all conditions are OK. The Cortex Controller shuts down the pump system when the engine RPMs are above safe operating speeds or the Cortex Controller determines that conditions are not correct for pump operation. The packing cycle will not begin if the RPMs are above a safe operating speed.

Refer to **Auto/Manual Pack Mode** in **Features** for operation of the Auto Pack feature.

Achieving Payloads

Read this section for advice and tips on how to pack the most efficient loads with your unit.

Payloads in any refuse/waste handling vehicle will vary greatly, depending on the type of material loaded. Dry bulk cardboard and reconstruction/building materials, Styrofoam, foam packing materials, loose plastic, etc. cannot be compressed and packed as effectively as wet, soft, garbage type materials. If dry materials can be mixed with some wet material, more effective payloads can be achieved.

Follow these techniques to attain greater efficiency in packing the load in your unit:

- 1. After you empty the first few bins, the body begins to fill and material can begin to "fall back" into the hopper
- 2. If the route allows, mix some wet bins in with dry bins. This helps compact the dry material more. Wet material also helps lubricate the body, which results in better packing.

LEAVING THE ROUTE FOR THE LANDFILL/ TRANSFER STATION

At the end of the route, or when the unit has a full load, prepare the unit to go to the landfill.

- The Body is fully LOWERED.
- The Tailgate is DOWN and LOCKED.
- The Lift Arm is in a transit position:
 - o The lift arm is fully stowed
 - The grabber arm assembly is against the chassis and the grabbers are fully open
- The Top Door (Hopper Cover) is:
 - For a unit before it is on-route CLOSED
 - o For an on-route unit OPEN
- The Packer Panel is:
 - For an empty unit, it is at the front of hopper.
 - For a unit with refuse in the body, it is up tight against refuse.
- The PTO or Pump Switch is OFF.
- The Mirrors are properly adjusted and clean.
- The Side Access Door and Sump Doors are CLOSED and LATCHED.
- ALL outside lights operate properly.
- The street side driver's station is used for traveling.

Use of Curbside Drive

If equipped, drive from the curbside driver position **ONLY** on the collection route. **DO NOT** use this station during travel to and from a route, landfill, or transfer station.

NOTES:

SECTION 9 LANDFILL/TRANSFER STATION/ RECYCLE CENTER PROCEDURES

PREVIEW

Read this section to learn about:

- Setup conditions to dump the refuse
- Unloading the refuse
- Using the sump and (optional) washout system
- Preparing the unit to return to route.

SETTING UP AN EJECT UNIT FOR UNLOADING

Set up the Unit

After positioning unit on firm stable ground for unloading at the landfill, set up as follows.

Make sure that all individuals are clear of the point of operation before actuating controls. Be ready to stop or reverse the function.

- 1. Shift the transmission to NEUTRAL.
- 2. APPLY the parking brake and MAKE SURE it is holding.
- 3. PRESS and RELEASE the pump (red) button on the Joystick to activate the Pump.
- 4. UNLOCK the tailgate by PUSHING and HOLDING the tailgate latch toggle switch (located in control panel in cab), until the tailgate is completely unlocked.

Raise the Tailgate

A DANGER

A tailgate in motion is dangerous. Serious injury or death may occur if a person is struck by a moving tailgate or becomes trapped between the tailgate and the body. Clear the area near the tailgate of all unnecessary people before you lower the tailgate.

Raise the Tailgate (Continued)

- 1. PRESS the TAILGATE UP/DOWN switch to UP and HOLD the switch until the tailgate is COMPLETELY raised, which is about 30° above the body. See the figure below.
- 2. RELEASE the switch.

NOTICE

The BODY TAILGATE UP notification turns ON and the in-cab alarm will sound to indicate the tailgate is open.



Figure 54. Raise the Tailgate

UNLOADING EJECT UNITS

After positioning unit on firm stable ground for unloading at the landfill and setting up as described in **Setting Up Eject Units for Unloading** [115], follow this procedure to unload a eject unit.

Stand clear when body is raised or unloading.

🏠 WARNING

Keep access doors closed when packer is in motion.

NOTICE

ALWAYS raise the tailgate BEFORE raising body.

Emptying the Body

- 1. With the tailgate completely raised, EJECT (remove) the refuse by depressing the packer extend pushbutton (green) on the Joystick (located in the cab) until all refuse is emptied out of the body and the packer panel comes to a complete stop. Release the button.
- 2. To retract the panel, depress the packer retract pushbutton (yellow) on the Joystick (located in the cab) until panel is completely retracted forward into the body. Release the pushbutton.



Figure 55. Ejecting the Refuse

UNLOADING AN EJECT UNIT (CONTINUED)

Prop the Tailgate

Before you clean and inspect the tailgate seal, prop the tailgate with the two factory body props. See **Propping the Tailgate**

Clean/Inspect Tailgate Seal

BEFORE you lower the tailgate, MAKE SURE the area where the tailgate seal mates with the body is CLEAN AND FREE of any refuse and debris. Inspect seal for possible excessive wear or damage and replace if necessary. Report any excessive wear or damage to your supervisor.

A DANGER

Stand clear when tailgate is in motion and during unloading cycle. Do not stand under or cross under raised tailgate. Doing so may result in injury or death.

Lower the Tailgate

- 1. PRESS the TAILGATE UP/DOWN switch to the UP position and HOLD to RAISE the tailgate sufficiently to rotate the props out of the prop pockets.
- 2. STORE the tailgate props.
- 3. PRESS the TAILGATE UP/DOWN switch to the DOWN position and HOLD to fully LOWER the tailgate until the tailgate flag is UP, then RELEASE the switch.

NOTICE

The BODY TAILGATE OPEN warning notification light will go OFF and the alarm will stop when body is FULLY down and the tailgate is completely closed.

Lock the Tailgate

Use the tailgate lock toggle switch to lock the tailgate.

UNLOADING AN EJECT UNIT (CONTINUED)

Clean Behind the Packer Panel

- 1. Extend the packer panel to the rear of the body.
- 2. Disengage the PTO or Pump Switch
- 3. Turn OFF engine and REMOVE the ignition key and place unit in Lock-Out/Tag-Out mode 55.

A DANGER

Before entering the body area, place the unit in Lock-Out/ Tag-Out mode. See Lock-Out/Tag-Out Procedures 55.

- 4. Open access door and clean behind the packer panel after each load.
- 5. Inspect packer tracks and hopper floor for excessive wear or possible damage.
- 6. Close access door and return packer panel to front of body.

Clean Out Hopper Sump

A sump door is located on the front corner on each side of the body and needs to be open when cleaning out the sump area. A cleaning tool is provided with each unit to clean out the sump area. Clean out the sump area after unloading at the landfill. Be sure to close and latch BOTH sump doors when completed.

NOTICE

Sump doors should be closed at all times except when open for cleaning.



Figure 56. Curb Side Hopper Sump Door Closed

Remove Refuse from the Engine and Exhaust Areas

Inspect unit for refuse on or about the engine or exhaust components. Remove all refuse to prevent a fire.

Preparing to Return to Route

MAKE SURE before you leave the landfill or transfer station that the unit is in the **In-Transit Position**

SETTING UP A DUMP UNIT FOR UNLOADING

Set up the Unit

After positioning unit on firm stable ground for unloading at the landfill, set up as follows.

Make sure that all individuals are clear of the point of operation before actuating controls. Be ready to stop or reverse the function.

- 1. Shift the transmission to NEUTRAL.
- 2. APPLY the parking brake and MAKE SURE it is holding.
- 3. PRESS and RELEASE the pump (red) button on the Joystick to activate the Pump.
- 4. UNLOCK the tailgate by PUSHING and HOLDING the tailgate latch toggle switch (located in control panel in cab), until the tailgate is completely unlocked.

Raise the Tailgate

A DANGER

A tailgate in motion is dangerous. Serious injury or death may occur if a person is struck by a moving tailgate or becomes trapped between the tailgate and the body. Clear the area near the tailgate of all unnecessary people before you lower the tailgate.

Raise the Tailgate (Continued)

- 1. PRESS the TAILGATE UP/DOWN switch to UP and HOLD the switch until the tailgate is COMPLETELY raised, which is about 30° above the body. See the figure below.
- 2. RELEASE the switch.

NOTICE

The BODY TAILGATE UP notification turns ON and the incab alarm will sound to indicate the tailgate is open.



Figure 57. Raise the Tailgate

UNLOADING A DUMP UNIT

After positioning unit on firm stable ground for unloading at the landfill and setting up as described in **Setting Up Dump Units for Unloading** 11, follow this procedure to unload a dump unit.

Make sure the unit is on firm, stable ground before you raise the body and clear the area of all unnecessary people. Make sure all tire pressures are correct. Do not prop a body unless it is on firm, stable ground. A unit not on firm, stable ground may roll when raising or propping the body. This may cause serious injury or death to you or bystanders.

A DANGER

Keep all parts of your body out from underneath the unit's body and away from the cylinders when raising or lowering the body. Serious injury or death will occur if the unit's body suddenly lowers and traps a part of your body. Always use the body props when you must leave the body raised for maintenance or cleaning operations.

Raising the body with the tailgate closed can damage the underride bumper. The underride bumper can hit the ground when the tailgate is not fully raised before you raise the body. Serious injury or death may occur.

Raising the Body

- 1. A unit with a tag axle may be unstable during dumping. ALWAYS lower the tag axle BEFORE you raise the body.
- 2. PRESS the TAILGATE UP/DOWN switch to UP and fully raise the tailgate, then RELEASE the switch.

NOTICE

Important: If a body raise cylinder hangs up for any reason as you raise the body, RELEASE the switch IMMEDIATELY so the body stops raising. Contact Heil Technical Service for more information.

3. PRESS the BODY UP/DOWN switch to UP and HOLD the switch until the body is COMPLETELY raised.

UNLOADING A DUMP UNIT (CONTINUED)

Raising the Body (Continued)

4. When the body is completely raised, RELEASE the BODY UP/DOWN switch.

Do not move the unit forward or backwards excessively fast (lurch) to dump the refuse load. Excessively fast movements with the body raised may make the body unstable and tip or roll the unit over. This may result in injury or death to the operator and damage the unit. Use only sufficient movement to loosen the load so that it will leave the body.

NOTICE

Do not move the unit forward or backwards excessively fast (lurch) to dump the refuse load. Excessively fast movements with the body raised puts a very high load on the body raise cylinders and could damage one or both cylinders and make the body unstable unable to lower. Inspect the cylinders after you dump each load and replace if necessary.

- 5. When the refuse stops falling out of the body, SLOWLY BUT SUDDENLY move the unit FORWARD a short distance and then STOP to allow more refuse to fall out of the body. Experience will teach you how fast to move safely forward or backward before you apply the brakes.
- 6. If necessary, perform step 5 again but go BACKWARD and then STOP to allow more refuse to fall out of the body.
- 7. Perform steps 5 and 6 as necessary to remove all of the refuse from the body.

UNLOADING A DUMP UNIT (CONTINUED)

Lowering the Body

ALWAYS lower the body BEFORE you lower the tailgate. If you used body props, MAKE SURE they are in the stored position BEFORE you attempt to lower the body.

Any part of your body between the unit's body and the chassis or cylinders while you raise the body is dangerous. Serious injury or death will occur if the unit's body suddenly lowers and traps a part of your body. Keep all parts of your body out from underneath the unit's body during this procedure.

- 1. PRESS the BODY UP/DOWN switch to the DOWN position.
- 2. HOLD the switch UNTIL the body fully mates with the chassis. When the body is COMPLETELY lowered, RELEASE the switch.

NOTICE

Important: If a body raise cylinder hangs up for any reason as you lower the body, RELEASE the switch IMMEDIATELY so the body stops lowering.

Prop the Tailgate

Before you clean and inspect the tailgate seal, prop the tailgate with the two factory body props. See **Propping the Tailgate** 93.

Clean and Inspect the Tailgate Seal

BEFORE you lower the tailgate, MAKE SURE the area where tailgate seal mates with the body is CLEAN AND FREE of any refuse and debris. Inspect the seal for possible excessive wear or damage and replace if necessary. Report any excessive wear or damage to your supervisor.

UNLOADING A DUMP UNIT (CONTINUED)

Lowering the Tailgate

A DANGER

A tailgate in motion is dangerous. Serious injury or death may occur if a person is struck by a moving tailgate or becomes trapped between the tailgate and the body. Clear the area near the tailgate of all unnecessary people before you lower the tailgate.

- 1. PRESS the TAILGATE UP/DOWN switch to the UP position and RAISE the tailgate sufficiently to rotate the props out of the prop pockets.
- 2. STORE the tailgate props.
- PRESS the TAILGATE UP/DOWN switch to the DOWN position and fully LOWER the tailgate, then RELEASE the switch.

NOTICE

The BODY TAILGATE OPEN warning notification light will go OFF and the alarm will stop when body is FULLY down and the tailgate is completely closed.

Lock the Tailgate

Use the tailgate lock toggle switch to lock the tailgate.

Clean Behind the Packer Panel

- 1. Extend the packer panel to the rear of the body.
- 2. Disengage the PTO or Pump Switch
- 3. Turn OFF engine and REMOVE the ignition key and place unit in Lock-Out/Tag-Out mode 5.

A DANGER

Before entering the body area, place the unit in Lock-Out/ Tag-Out mode. See Lock-Out/Tag-Out Procedures 5.

- 4. Open access door and clean behind the packer panel after each load.
- 5. Inspect packer tracks and hopper floor for excessive wear or possible damage.
- 6. Close access door and return packer panel to front of body.

UNLOADING A DUMP UNIT (CONTINUED)

Clean Out Hopper Sump

A sump door is located on the front corner on each side of the body and needs to be open when cleaning out the sump area. A cleaning tool is provided with each unit to clean out the sump area. Clean out the sump area after unloading at the landfill. Be sure to close and latch BOTH sump doors when completed.

NOTICE

Sump doors should be closed at all times except when open for cleaning.



Figure 58. Curb Side Hopper Sump Door Closed

Remove Refuse from the Engine and Exhaust Areas

Inspect unit for refuse on or about the engine or exhaust components. Remove all refuse to prevent a fire.

Preparing to Return to Route

MAKE SURE before you leave the landfill or transfer station that the unit is in the **In-Transit Position** 105.

SECTION 10 CORTEX CONTROLLER™

Copyright 2017, Heil Environmental Printed in U.S.A.

PREVIEW

Read this section to learn about:

- Troubleshooting the Cortex Controller
- Operational specifications
- Hydraulic Filter Bypass
- Diagnostic Fault Codes

CORTEX CONTROLLER™ INSIGHT™ DIAGNOSTIC DISPLAY NOTIFICATIONS

When a fault has been set the In-Cab Alarm will sound a number of beeps that indicate which fault has occurred. See **Diagnostic Fault Codes** Service Manual Automated Side Loader Cortex Controller[™] Program 109-0285 for more information.

NOTICE

The In-Cab alarm is overridden by the Tailgate/Body alarm. For example, if the tailgate is open or the body is raised on Eject units, the alarm will sound for 2 seconds and pause for 10 seconds until that condition is resolved. Any diagnostic codes that are still present after the tailgate alarm has been resolved will then sound.

Hydraulic Pump Shutdown

The unit's pump shutdown system turns off the hydraulic pump when the return line filter becomes blocked (clogs) which starts the filter bypass system.

The sequences 1 through 3 occur after the filter clogs and bypass begins.

NOTICE

A filter bypass condition allows you to operate the hydraulic pump when the return line filter is blocked with sediment and other materials. You can cause damage to hydraulic components if you operate the unit with a blocked hydraulic oil filter. Change the filter as soon as you can.

- START OF BYPASS TO END OF FIRST (1st) HOUR – The bypass light does not come on and the Cortex Controller does not beep.
- 2. SECOND (2nd) HOUR THROUGH FIFTH (5th) HOUR OF BYPASS – The filter bypass light flashes ON and OFF after the first full hour of bypass. The number of ON flashes indicates the number of full hours of bypass. The time the flash is OFF starts at about 5 seconds (for the first full hour of bypass) and decreases about 1 second for each full hour of bypass beginning with the second full hour of bypass the OFF time. For example, during the third hour of bypass (two complete hours of bypass), the light flashes ON twice and is OFF for approximately 4 seconds and the cycle repeats.
- 3. SIXTH (6th) HOUR AND AFTER The pump will function for three minutes. The filter bypass light comes ON solid. The Cortex Controller beeps 13 times in a minute, pauses and the cycle repeats until you change the filter.

CORTEX CONTROLLER™ INSIGHT™ DIAGNOSTIC DISPLAY NOTIFICATIONS (CONTINUED)

Hydraulic Pump Shutdown (Continued)

4. UNTIL YOU CHANGE FILTER - You can operate the pump for three (3) minutes at a time until you change the filter. You can turn the pump OFF then turn it back ON.

After Hydraulic Filter Change

- 1. The Cortex Controller[™] alarm continues to beep until the filter is clear for 15 minutes, then stops and the filter bypass light goes OFF.
- 2. To start the hydraulic system after you change the filter:
 - MAKE SURE the SYSTEM POWER switch is ON.
 - PRESS the PUMP ON switch.
- 3. The filter must stay clean for 15 minutes before the Cortex Controller resets the shutdown timer and normal operation resumes.

NOTES:

DIAGNOSTIC FAULT CODES

Each fault code consists of a two digit number. When a fault condition occurs, the in-cab buzzer will sound for five (5) seconds, then stop. It will then beep a number of times specifying the first digit of the code. The beep will pause for two (2) seconds, then resume to beep a number of times specifying the second digit of the code. Refer to the table to the right and the decal in the cab for definitions of warnings or fault conditions.

Fault Disabled Functions

Certain critical fault codes will disable the normal operation of some body functions. This is intended to avoid any potential damage that might result from the malfunction. These functions will remain disabled until the fault condition has been resolved and the fault code has been cleared. Some less critical fault conditions will not disable any of the body functions, but simply set a beep code.

For more information, refer to the Service Manual Automated Side Loader Cortex Controller™ Program 109-0285.

DIAGNOSTIC FAULT CODES						
BEEP CODE	DEFINITION OF WARNINGS OR FAULT CONDITION					
31	HIGH TRANSMISSION TEMPERATURE					
32	FILTER BYPASS SHUTDOWN					
33	SIDE DOOR INTERLOCK					
34	LOW HYDRAULIC OIL (OPTIONAL)					
35	DEAD MAN JOYSTICK FAULT (OPTIONAL)					
41	ENGINE SPEED NOT DETECTED					
42	LOSS OF ENGINE IDLE CALIBRATION					
43	LOSS OF ENGINE TACH. CALIBRATION					
53	PACKER PROX. FAULT					
54	FILTER PRESSURE SWITCH FAULT (OPTIONAL)					
55	PACKER PRESSURE SWITCH FAULT					
23	TORQUE LIMIT PRESSURE SWITCH FAULT (OPTIONAL)					

NOTES:

SECTION 11 END OF DAY PROCEDURES

Copyright 2017, Heil Environmental Printed in U.S.A.

PREVIEW

Read this section to learn about:

- Parking the Unit
- Washout System
- Final Inspection
- Report to Employer/Supervisor
- Ignition Keys

END OF DAY PROCEDURES

Parking the Unit

- 1. Park the unit in the space designated by your employer/supervisor.
- 2. Set the parking brake.

Washout System

If the unit has a washout system and you did not use it at the landfill/transfer station, you should clean the body and hopper, unless your employer has a different policy. If your employer's policy is different from this manual, follow their policy.

Final Inspection

Perform a final inspection of the unit:

- 1. Clear the area of all people.
- 2. Start the engine if it is not running.
- 3. Make sure all lights and in-cab control switches operate correctly.
- 4. Put the transmission in reverse while you press the service brake. The backup alarm should sound in the cab. If the alarm does not sound in the cab, report this to your employer/supervisor immediately.
- 5. Check the unit for fluid leaks from the hoses, cylinders, valves, pump and fittings. Report any leaks to your employer/supervisor.

- 6. Make sure all cylinders (except tailgate lock cylinders and arm raise cylinders) are in their retracted position.
- 7. APPLY the parking brake.
- 8. Put the transmission in neutral and turn the engine OFF.
- 9. Put the unit in the Lock-Out/Tag-Out mode 57.
- 10. Open the air tank drain valve.
- 11. Turn the battery disconnect switch to OFF.
- 12. Follow the company policy for locking the cab doors.

Reports to Employer/Supervisor

Complete any reports required by your employer/ supervisor. If you found any problems during the final inspection, prepare the necessary report for the employer/ supervisor.

Ignition Keys

Put the ignition keys in a secure storage area designated by your employer/supervisor.

NOTES:

SECTION 12 PREVENTIVE MAINTENANCE CHART

Copyright 2017, Heil Environmental Printed in U.S.A.

BODY PREVENTIVE MAINTENANCE CHART

Preventive maintenance must be performed to ensure the safe and reliable operation of your unit. Use the chart below as a guideline for when essential items should be checked and serviced.

*HOURS OF OPERATION								
COMPONENT/SYSTEM		40	200	1000	2000	CHECK/SERVICE		
Hydraulic System						Check oil level – add if necessary		
						Check cylinders, pump, hoses, tubes, fittings, and adapters for leaks. Check hoses for cracks, crushes, and cover blisters. Repair or replace if necessary with genuine Heil parts. Any replacement hose should be the same size and pressure rating as listed on the original OEM hose.		
		R				Check Control valve seals for leaks. Repair or replace if necessary.		
						Replace filter after first 30 days of operation, then every 6 months or 1000 hours of operation OR when filter bypass light is ON.		
						Replace tank breather filter every time you replace filter element.		
						Drain, flush, and refill. Change filter element.		
Electrical, Battery Cables						Check for proper operation.		
						Check battery cables from battery to starter for loose cables, rubbing or damage and abrasions to cables. Replace if necessary.		
*HOURS OF OPERATION								
--	-------------------	----	-----	------	------	---	--	
COMPONENT/SYSTEM	8	40	200	1000	2000	CHECK/SERVICE		
Operator Controls	$\mathbf{\nabla}$							
Front Mount Pump or Power Take-Off (PTO)						Check seals for leaks and operation. Replace if necessary		
						Check drive line for smooth operation. Replace as necessary.		
		N				Check set screws for tightness. Tighten as necessary.		
		N				Make sure keys are in place. Replace if necessary.		
						For greaseable PTOs (non-wet spline), remove the pump's bolt flange about 2 inches from the PTO and apply grease to female pilot of PTO pump flange. Failure to lubricate female pilot of PTO as given may cause damage to the pump shaft. Greasing is NOT required on wet spline PTOs such as the Chelsea 890/897 series.		
Grease Fittings						Lubricate as shown on Body Lube Chart.		
Body Undercoating						Inspect body undercoating and repair as necessary.		
Fork Bearing Block Bolts (Half/Pack [®] and Odyssey™ Models Only)						Each of the four fork bearing block bolt torques should be 460 Ft-Lbs.		
Calibrate Cylinder Sensors (Odyssey™ Models Only)						For Odyssey models only, calibrate cylinder sensors. See Service Manual - Odyssey Cylinder Sensors Calibration.		
* Daily = 8 hrs. Weekly = 40 hrs. Monthly = 200 hrs. 6 Months = 1000 hrs. Yearly = 2000 hrs.								

NOTES:

SECTION 13 LUBRICATION GUIDE

Copyright 2017, Heil Environmental Printed in U.S.A.

BODY LUBRICATION GUIDE

Clean fittings before applying grease and always pump enough grease into joint to remove the old grease. Wipe off excess grease. Lubricate moveable mechanical parts without fittings every 60 days with non-detergent engine oil. Also refer to the chart on the next page.



Figure 59. Body Lubrication Guide

BODY LUBRICATION GUIDE (CONTINUED)

Clean fittings before applying grease and always pump enough grease into joint to remove the old grease. Wipe off excess grease. Lubricate moveable mechanical parts without fittings every 60 days with non-detergent engine oil. Also refer to the image on the previous page.

REF NO.	DESCRIPTION	QTY.	FREQUENCY
1	Tailgate Cylinders	4	Weekly/Every 50 Hours
2	Hoist Cylinder	4	Weekly/Every 50 Hours
3	PTO Drive Shaft	3	Weekly/Every 50 Hours
4	Rear Body Pivot Hinge	2	Weekly/Every 50 Hours
5	Packer Cylinders	4	Weekly/Every 50 Hours
5A	Tailgate Lock Bearing	4	Weekly/Every 50 Hours
6	Tailgate Hinge	2	Weekly/Every 50 Hours
7	Packer Panel Tracks	-	Monthly/Every 200 Hours

LIFT LUBRICATION GUIDE

Clean fittings before applying grease and always pump enough grease into joint to remove the old grease. Wipe off excess grease. Lubricate moveable mechanical parts without fittings every 60 days with non-detergent engine oil.



Figure 60. Lift Arm Lubrication Guide

SECTION 14 COMPRESSED NATURAL GAS (CNG) OPTION

Copyright 2017, Heil Environmental Printed in U.S.A.

IMPORTANT SAFETY INFORMATION

NOTICE

For CNG units, this manual should be used in conjunction with any associated CNG System Manufacturer's Operation and Maintenance Manuals. Always read and understand all associated manuals alongside the Heil Operation Manual and Heil Parts and Service Manual before operating or servicing the unit. CNG training is required for any person inspecting, operating, or performing maintenance on a CNG unit.

Read, understand and follow the instructions within this document before operating, servicing or adjusting referenced equipment. Anyone using or maintaining this equipment must be familiar with the product and fully trained. Improper usage or maintenance of this equipment may result in injury or death.

Always keep a copy of this manual readily available for persons who operate the equipment or perform maintenance procedures. Safe working procedures must be followed at all times. Lock-Out/Tag-Out procedures must be followed when performing applicable procedures.

A vehicle equipped with a compressed natural gas fuel system will have a blue reflective decal on the rear of the vehicle identifying Compressed Natural Gas (CNG). See the image below.



IMPORTANT SAFETY INFORMATION (CONTINUED)

A. Safety Notices

Throughout this manual, safety notices are included to warn operators and maintenance technicians of the dangers associated with the described equipment operations and maintenance. Improper operation or maintenance procedures may cause serious injury or death. Safety notices accompany potentially hazardous situations throughout this manual. Please read and follow instructions carefully.

For supplemental information, refer to the following codes:

- United States: NFPA 52, State and Local Regulations
- Canada: CAN/CGA B109, CAN/CSA B108, FMVSS 304

A DANGER

The CNG Fuel Module System contains some lines that are under continuous high pressure. DO NOT attempt to loosen or disconnect those lines.

A DANGER

Natural Gas is Flammable and Explosive. Never use an open flame (match, lighter, or other) to light a work area near the CNG fuel storage system.

A DANGER

Keep work area well ventilated to avoid asphyxiation due to concentrated levels of carbon monoxide.

Do not start the engine if a natural gas leak is detected.

IMPORTANT SAFETY INFORMATION (CONTINUED)

Never open system components while the system is under pressure. Treat all cylinders as full until defueling has been completed.

Never weld or perform any type of "hot work" on any part of a compressed natural gas vehicle unless the compressed natural gas fuel system has been purged with inert gas.

A WARNING

Avoid open flames and sparks near a compressed natural gas vehicle.

Do not smoke cigarettes, cigars, or use any other lit or sparking items within 30 feet of a compressed natural gas vehicle or a dispensing/filling station.

Do not use a cell phone or other electronic device within 30 feet of a compressed natural gas vehicle or a dispensing/filling station.

Keep the compressed natural gas equipment area well ventilated.

A portable fire extinguisher must be installed on the vehicle in an accessible location.

COMPRESSED NATURAL GAS (CNG) FUEL MODULE

The images on the following pages show a typical CNG system configuration. Your CNG system configuration may vary.

A. Fuel Module Functions

The CNG fuel tanks contain CNG at a pressure of 3,600 psi in USA, (3,000 psi in Canada). The CNG Fuel Module serves multiple functions within a natural gas vehicle (NGV) fuel system.

These functions include:

- Storage tank refueling
- Storage tank pressure measurement
- Manual and ignition controlled fuel shut-off
- Pressure reduction from storage tanks to engine supply
- Fuel system filtration
- Liquid removal from fuel system

B. Fuel Module Components

1. High Pressure Gauge

The high pressure gauge, located in the front panel of the fuel control module, indicates the pressure of the CNG being supplied to the regulator. If the manual shut-off valve is turned to 'on' and all other valves are open between the fuel tank and the fuel control module, this gauge reflects fuel tank pressure.

2. Low Pressure Gauge

Located below the high pressure gauge in the front panel of the fuel control module, the low pressure gauge indicates the pressure of the CNG leaving the regulator and supplying the vehicle's engine. A typical reading for this gauge is 100-120 psi, dependent upon regulator setting.

COMPRESSED NATURAL GAS (CNG) FUEL MODULE (CONTINUED)

B. Fuel Module Components (Continued)

3. Manual Shut-Off Valve

The manual shut-off valve is located on the bottom front of the fuel control module. Rotate the handle clockwise so arrow turns down and points to the 'OFF' position to prohibit fuel flow from the tanks to the vehicle's engine. Rotate the handle counterclockwise so arrow points to the 'ON' position to allow fuel flow from the tanks to the vehicle's engine.



Figure 61. Manual Shut-Off Valve

4. Purge Valve

Located inside the side maintenance access door, the purge valve, when loosened counterclockwise, purges CNG from the vehicle's fuel control module to allow safe access to the filter assembly.



Figure 62. Purge Valve

COMPRESSED NATURAL GAS (CNG) FUEL MODULE (CONTINUED)

B. Fuel Module Components (Continued)

5. Fuel Filter

The fuel filter is located inside the side maintenance access door, within the filter bowl. This filter collects both solid and liquid contaminants. It requires periodic maintenance, as outlined in **CNG Fuel Module Maintenance and Part Replacement** in the Compressed Natural Gas (CNG) section of your Service Manual.



Figure 63. Side Maintenance Access

PROPERTIES OF NATURAL GAS

- Auto Ignition Point: 900 1170° F (482 632°C)
- Lower Explosive Limit (%): 3.8 6.5
- Upper Explosive Limit (%): 13 17

CNG VEHICLE OPERATOR EMERGENCY RESPONSE

A vehicle equipped with a compressed natural gas fuel system will have a blue reflective decal on the rear of the vehicle identifying compressed natural gas (CNG).

During an emergency situation, never jeopardize safety to shut down the system. If it becomes evident that the steps cannot be safely completed, move to a safe distance, call 9-1-1 and alert emergency personnel of the situation, informing them of the presence of a CNG system and that it is not properly shut down.

Emergency Response for Gas Leaks

If the vehicle has sustained damage or a gas leak is detected:

- 1. Do not approach the vehicle if any sources of ignition may exist such as fire, sparks, electrostatic charges, lights or electronic devices.
- 3. If the vehicle is indoors, move the vehicle outside and away from any ignition sources.
- 4. Do not use road flares.
- 5. Do not smoke or allow anyone else to smoke near the vehicle.
- 6. Turn the ignition switch off, set the parking brake and turn off the battery at the main disconnect.

- If it is safe to do so, close the main shutoff valve and the cylinder valves. Check the fuel system near the damaged area for leaks by smell, sight, and sound. CNG is odorized and can be detected by smell.
- 8. Keep traffic and pedestrians away.
- 9. Beware that gas may continue to leak once ignition is turned off and the manual shutoff valves are closed.
- 10. Have a qualified technician verify leak locations with suitable methane detection fluid.
- 11. Have the leaks repaired by a qualified technician immediately.

Vehicle Fire Procedures

In the event of a CNG fire, it is imperative that the vehicle operator acts quickly:

- 1. Get passengers out of the vehicle as quickly as possible.
- 2. Evacuate the area.
- 3. Call 9-1-1.
- 4. If possible without putting yourself in harm's way, dump the refuse load from the body and move the vehicle a safe distance away from any burning refuse.

CNG VEHICLE OPERATOR EMERGENCY RESPONSE (CONTINUED)

CNG Vehicle Emergency Shut Down Procedure

During an emergency situation, never jeopardize safety to shut down the system. If it becomes evident that the steps cannot be safely completed, move to a safe distance, call 9-1-1 and alert emergency personnel of the situation, informing them of the presence of a CNG system and that it is not properly shut down.

Complete the following steps to shut down the CNG system:

- 1. Turn OFF Ignition and Electrical System.
- 2. Turn OFF Fuel Module Manual Shut-Off Valve.
- 3. Close each Tank Valve.
- 4. Call Technical Services at 866-310-4345 for further assistance.

Emergency Venting/Defueling Procedure

If an emergency arises in which the fuel must be purged immediately, an emergency vent can be performed as follows:

- 1. Ensure that an electrical ground connection has been established between the cylinders, the vent system, and earth ground.
- 2. Connect the on-board defueling connection to the vent system using a conductive high pressure defueling hose.
- 3. Slowly open the hand valve to achieve a slow and steady flow to prevent freezing. No gas flow may indicate a normally closed solenoid valve on the cylinder. Consult the vehicle manufacturer for information on opening electronic solenoids.
- 4. Allow the on-board storage system to vent completely.
- 5. When completed, disconnect the on-board defueling connection from the vent system and disconnect the earth ground.

CNG FRONT OF BODY / TOP OF BODY DECAL PLACEMENT

In addition to the decal shown below, there may be other decals placed on the fuel management module (FMM), tank compartments or elsewhere on the CNG system components. Refer to the CNG System Manufacturer's Operation and Maintenance Manuals for replacement decal part numbers.







FUEL MANAGEMENT MODULE (FMM) DECAL

CNrG™ TAILGATE DECAL IMAGES





This vehicle uses Compressed Natural Gas (CNG) fuel supplied from multiple tanks located inside the tailgate.

212-3387

Figure 66. Warning: Vehicle uses CNG fuel, PN 212-3387



Figure 67. Manual Shutoff Valve, PN 212-3280

CNrG™ TAILGATE DECAL IMAGES



Figure 68. Patent Pending, PN 45002153

Compressed Natural Gas (CNG) tank must be empty before removing transducer.

212-3388

Figure 70. Warning, CNG tank empty before removing transducer, PN 212-3388

WARNING

Never weld on a Compressed Natural Gas vehicle unless the Compressed Natural Gas fuel system has been purged with inert gas. 212-3286

Figure 69. Warning, CNG tank empty before removing transducer, PN 212-3286

ANOTICE

ALL Compressed Natural Gas (CNG) transducers MUST be functioning for system to be able to detect a leak.

Figure 71. Notice: Transducers MUST be functioning, PN 212-3389

CNrG™ TAILGATE DECAL IMAGES



212-3400

STARTING VEHICLE

NOTICE

Starting a natural gas vehicle requires a delay between the battery power being turned on and the starter motor being activated.

- 1. Make sure that the system has been properly leak tested and that no leaks exist.
- 2. Make sure that plastic caps are installed on all exposed vent lines. For tailgate mounted CNG, vent lines route to the top of the tailgate. If the plastic caps are missing, contact Heil Parts Central for replacement caps (Part Number 042-2078 for 3/8" and 042-2079 for 1/2") at 800-528-5308.
- 3. Make sure that the cylinder shut-off valves (one on each cylinder) are "OPEN" and the manual shut-off valve is "ON".
- 4. Without starting the engine, turn the key to the "RUN" position and wait 20-30 seconds. This will allow the fuel to properly fill the system and provide adequate back-pressure for the high-pressure solenoid valve to function properly.
- 5. Start the engine.
- 6. If this is the first start of the day, let the vehicle idle for five minutes. This will allow coolant to warm the fuel and ensure that the low-pressure lines down-stream of the primary pressure regulator do not freeze up. On extremely cold days, the vehicle may have to idle for a longer period until the fuel warms adequately.

FUELING PROCEDURE

A. CNG Fueling Steps

Two options exist for filling a vehicle with CNG – timed fill or fast fill. Despite the size of the receptacle, the fueling hose connects in the manner for either type of fill.

The steps include:

1. Locate the fueling fill receptacle in the CNG fuel module.

NOTICE

Optional, fill receptacles may be installed in a remote location on the vehicle's front bumper.

- 2. Remove the dust cover on the fill receptacle.
- 3. Remove fueling nozzle from the CNG dispenser holder.
- 4. Begin fueling the CNG vehicle.
- 5. When complete, disengage the Fueling Nozzle.
- 6. Return the nozzle to the CNG dispenser.
- 7. Replace the dust cover on the receptacle.
- 8. Close the CNG fuel module door and engage door lock.

FUELING PROCEDURE (CONTINUED)

B. Types of Fueling Hoses

Dependent upon the fueling station, different types of fueling hoses may be utilized. Refer to the figures below and on the next page to determine which type of fueling hoses you will be using.

1. Type 1:

When utilizing this type of nozzle, follow directions below to refuel:

- a. Slide the nozzle over the receptacle intake. In order to properly engage the fill hose with the receptacle, hold the nozzle in one hand. With the free hand, twist the lever counterclockwise to line up the two arrows, facing each other. Complete the connection by pushing the fueling hose fully onto the receptacle.
- b. Once the hose fits completely onto the fill receptacle, you will hear a click and the arrow on the lever will shift, misaligning with the arrow on the actual hose. This indicates that the hose fueling nozzle is properly seated onto the receptacle.
- c. When the hose fully connects, turn the lever clockwise until both arrows are pointing toward the fill receptacle to begin fueling.
- d. When fueling is complete, release the nozzle connection. Holding the nozzle in one hand, use the other hand to turn the nozzle so that arrows again point toward each other (as shown in step "a"). You will hear a release of pressure.

e. Disconnect the fuel hose, and return it to the fuel dispenser.



Figure 73. Type 1 Fueling Hoses



***NOTE: Arrows must be aligned as shown to allow proper engagement of the hose with the fill receptacle.

Figure 74. Type 1 Fueling Hoses

FUELING PROCEDURE (CONTINUED)

- B. Types of Fueling Hoses (Continued)
 - 1. Type 1 (Continued):



Figure 75. Type 1 Fueling Hoses

2. Type 2:

This fueling hose operates in the following manner:

- a. Locate fill receptacle and remove dust cap.
- b. Slide fueling hose nozzle onto the fueling receptacle.
- c. Compress the hand grip until the locking lever engages.
- d. Begin fueling.
- e. When complete, release the locking lever and disconnect the fueling hose.



Figure 76. Type 2 Fueling Hose

FUELING PROCEDURE (CONTINUED)

3. Type 3:

To utilize this hose:

- a. Locate fill receptacle and remove dust cap.
- b. Holding firmly, press nozzle onto fill receptacle.
- c. Rotate lever clockwise 180° to begin fueling.
- d. When fueling is complete, rotate lever counterclockwise 180° to allow fuel hose disconnection.



Figure 77. Type 3 Fueling Hose

TRANSFER FUELING (DEFUELING) MODES, COMPONENTS AND PROCEDURES

Defueling is generally the process of removing any residual fuel from the fuel tanks and on-board fuel delivery system prior to performing any welding or a major repair. Capturing the CNG in a system that can send it back to a CNG fueling station storage facility for reuse is the most environmentally responsible method. Atmospheric venting of CNG might be illegal and against local environmental regulations for your area. Check local laws and regulations before venting CNG to the atmosphere.

Before attempting to defuel a CNG vehicle, read and understand National Fire Protection Association (NFPA) 52 sections 6.14.1 - 6.14.4.4 as they provide a detailed list of requirements to be followed when performing defueling. Also read and understand all of the safety alert messages and procedures in this section. Maintenance of a compressed natural gas system is to be performed ONLY by authorized service personnel.

Basic Rules for Defueling

- Consume as much fuel as possible prior to defueling
- Notify appropriate nearby personnel prior to defueling and clear the area of all unessential people
- ALWAYS ground (earth ground) the vehicle AND the fuel system being defueled
- NEVER defuel indoors
- Always wear personal protective equipment
- Be familiar with evacuation routes

DuraPack[®] Python[®]

TRANSFER FUELING (DEFUELING) MODES, COMPONENTS AND PROCEDURES (CONTINUED)

A. CNG Fuel Module Defueling Functions

The fuel module is equipped with a defueling functionality. This allows the transfer of CNG fuel into the fill receptacle of a second CNG vehicle, using a defueling hose, or capturing of CNG fuel in a system that can send it back to a CNG fueling station storage facility for reuse.

NOTICE

The defueling process does not deplete the CNG fuel in the supplying (defueling) vehicle. The pressure in both tanks will be equalized with CNG fuel after the defueling process is completed. To completely deplete the CNG fuel from a vehicle, the defueling hose can be connected to a CNG fuel recovery system instead of a second vehicle.

B. CNG Fuel Module Defueling Operating Modes

When the Defueling Selector Valve is positioned to the "Normal Operation" position, the defueling receptacle is vented to the atmosphere to allow disconnection of the defueling hose.

When the Defueling Control Valve is positioned to the "Defueling Enabled" position, CNG fuel from the storage tanks can flow to the Defueling Receptacle.



Figure 78. Fuel Module Defueling Selector Valve Set

DEFUELING

C.CNG Fuel Module Defueling Components

DEFUELING SELECTOR VALVE

NORMAL

OPERATION

Defueling components are located on the front panel of the fuel module. The components include:

- 1. Defueling Receptacle connection point for transferring CNG fuel out of the fuel system.
- 2. Defueling Selector Valve facilitates CNG fuel transfer



Figure 79. Fuel Module Defueling Components

TRANSFER FUELING (DEFUELING) MODES, COMPONENTS AND PROCEDURES (CONTINUED)

- 3. Defueling Hose
 - a. The Defueling Hose (if available) is to be used for the purpose of transferring CNG fuel from a supplying (defueling) vehicle to a receiving (fueling) vehicle.
 - b. The tank pressure of the supplying vehicle must be higher than the tank pressure of the receiving vehicle in order for CNG fuel to transfer.
 - c. Once the two (2) vehicles' tank pressures have equalized due to the transfer of CNG fuel, no further transfer of CNG fuel will occur.
 - d. In order to use the Defueling Hose, the vehicle being defueled must be equipped with a defueling receptacle.
 - e. If the vehicle is not equipped with a defueling receptacle, then the defueling operation is not possible using the Defueling Hose Assembly.

E. CNG Fuel Module Defueling Methods

There are three methods by which to defuel a CNG vehicle using a Defueling Panel with a Defueling Receptacle. If your unit has the **Heil CNrG™ Solenoid System** option, the ignition must be left ON while defueling in order for all tanks to defuel. See **Heil CNrG™ Solenoid System Option Tree Solenoid System Option Solenoid Solenoid System Option Solenoid Solenoid System Option Solenoid S**

Venting does not completely empty the system of combustible gas. Never weld on a compressed natural gas vehicle unless the compressed natural gas fuel system has been purged with inert gas. See **Paragraph F** $rate{164}$.

- 1. Defueling to Another Vehicle
 - a. Prior to connecting the defueling hose to either vehicle, open the purge valve on the hose to release any residual pressure that may be in the hose.
 - b. Close the purge valve and continue.
 - c. Position the defueling control valve on the fuel module in the "Normal Operation" position. This will release any pressure in the defueling circuit and allow the hose's defueling nozzle to be connected to the defueling receptacle.
 - d. If the valve is not in this position, it will not be possible to make the connection.
 - e. Connect the hose's defueling nozzle to the defueling receptacle of the fuel module on the supplying (defueling) vehicle.

TRANSFER FUELING (DEFUELING) MODES, COMPONENTS AND PROCEDURES (CONTINUED)

- 1. Defueling to Another Vehicle (Continued)
 - f. Connect the hose's fueling nozzle to the NGV1 fueling receptacle on the receiving (fueling) vehicle.
 - g. Turn the defueling control valve on the supplying (defueling) vehicle to "Defueling Enabled". This will initiate the flow of CNG fuel from the supplying vehicle to the receiving vehicle.
 - h. To stop the flow of CNG fuel, turn the Defueling Control Valve to the "Normal Operation" position. This will stop the flow of CNG fuel and vent the pressure in the defueling hose so that it can be disconnected. If the supplying vehicle is not equipped with a defueling control valve which automatically vents the pressure in the hose when the flow of CNG fuel is stopped, then the purge valve must be used to vent the hose, allowing disconnection of the hose from the receptacle.
- 2. Atmospheric Venting Method
 - a. You must first check to see if this method is legal in your area. There could be local environmental regulations regarding the release of methane into the atmosphere.

- b. If atmospheric venting is acceptable in your area, then a vent stack apparatus that meets the requirements established in either the Uniform Building Code or the International Building Code must be followed as well as NFPA 52.
- c. With the local authority having jurisdiction, typically the Fire Marshal should be consulted.
- d. BOTH the vehicle AND the fuel system should be grounded. Use a minimum 14-gauge multistranded wire. Contact the CNG system manufacturer for attachment points for the ground wire.
- e. Restrain all tanks during depressurization to prevent the tanks from moving.
- f. Attach a defueling nozzle to the defueling receptacle. Contact the CNG system manufacturer for the minimum distance the vent hose should be positioned above the ground.
- g. After this nozzle is connected, the valves that allow system pressure to reach the defueling receptacle must be turned to the "defueling enabled" position (if equipped).
- 3. Compressor Inlet Method
 - a. This procedure requires pre-planning and special equipment installed at the CNG fueling station. Check with your CNG fueling station supplier or installer.
 - b. In this method, the vehicle is connected through the fueling nozzle to the defueling panel receptacle and the compressor at the fueling station extracts the compressed natural gas from the vehicle.

TRANSFER FUELING (DEFUELING) MODES, COMPONENTS AND PROCEDURES (CONTINUED)

- 3. Compressor Inlet Method (Continued)
 - c. BOTH the vehicle AND the fuel system should be grounded. Use a minimum 14-gauge multistranded wire. Contact the CNG system manufacturer for attachment points for the ground wire.
- F. Purging with an Inert Gas Prior to Welding or Major Repairs

If welding or major repairs is required, you must remove all of the fuel from the vehicle including the residual fuel and replace it with an inert gas such as nitrogen. The objective is to completely purge the system of all combustible gas. In order to complete the operation, the entire system should be purged with the inert gas 3 times to a pressure of at least 689kPa (100 psig). Approximately 70kPa (10 psig) of residual inert gas pressure should be left on the system during the major repair.

A WARNING

Never weld on a compressed natural gas vehicle unless the compressed natural gas fuel system has been purged with inert gas.

NOTICE

Avoid exposing CNG system parts to molten metal from weld, torch, cutting, or grinding splatter. The CNG system and/or the CNG system components can be damaged.

G.Recharging the Fuel System after Purging and after Major Repairs

After repairs, the inert gas must be removed from the system in a similar manner as the inert gas was introduced. Specifically, the entire system should be charged 3 times with approximately 689kPa (100 psig) of natural gas. Between each natural gas charging session, the system should be vented or extracted to remove the remaining inert gas from the system. See the Notices below and the atmospheric venting method instructions on the previous page.

NOTICE

It is critical when venting between gas charging sessions to make sure the tank pressure never goes below 34kPa (5 psig). 69-138kPa (10-20 psig) is the recommended cutoff for this procedure. This will ensure that outside air does not re-enter the tank due to the pressure dropping too low in the tank.

NOTICE

If venting to atmosphere, you must first check to see if this method is legal in your area as some natural gas will be vented along with the inert gas.

CNG SYSTEM MAINTENANCE

Routine maintenance of the compressed natural gas system in accordance with the **Table 1. Inspection/Preventive Care Schedule** (next page) will ensure that the system and components are functioning properly. See the **Compressed Natural Gas (CNG)** section of your Service Manual for additional maintenance information.

System components must not be under pressure during servicing. Servicing components under pressure may cause serious injury.

Never weld on any part of a compressed natural gas vehicle unless the compressed natural gas fuel system has been purged with inert gas.

Make sure the unit is in the Lock-Out/Tag-Out mode when you do maintenance or service procedures, or when you go in the hopper, climb in or on the body or on equipment. The unit can be operated intentionally or accidentally when the unit is not in the Lock-Out/Tag-Out mode which can cause serious injury or death to anyone in the hopper, in or on the body or on equipment.

Maintenance of a compressed natural gas system is to be performed ONLY by authorized service personnel. Unauthorized maintenance can result in personal injury and/or extensive damage to the unit.

DuraPack[®] Python[®]

INSPECTION/PREVENTIVE CARE SCHEDULE

Table 1. Inspection/Preventive Care Schedule

ITEM	FREQUENCY		
Storage System:			
Leak Test with Methane Detector*	Every month		
Component Inspection*	Every month		
Drain Filter	Every 10,000 miles		
Replace Filter Element	Every 40,000 miles		
Drain Vent Lines	Every month (or immediately if blue vent cap is missing)		
Cylinders*	Inspect compressed gas cylinders as outlined by cylinder manufacturer		
* To be completed by a qualified and trained person.			

PREPARATION BEFORE MAINTENANCE

It is necessary to prepare the truck to be serviced. A mechanic's initial focus while preparing the vehicle for service should be safety. The primary preparation involves relieving the pressure within the system BEFORE performing any maintenance procedures.

Follow the steps as outlined to ensure that no pressure remains.

1. Leave the Fuel Management Module Manual Shut-Off Valve in the 'ON' position. 2. Turn OFF each supply tank's valve(s) inside CNrG Tailgate.



Figure 80. Tank Valve

- 3. Start the vehicle's engine, allowing it to run until the engine shuts off. This will ensure that all CNG in the lines has been consumed.
- 4. As an added safety precaution, open the system purge valve to ensure no latent pressure remains.
- 5. Ensure the high pressure gauge on the fuel control module reads 0 psi.
- 6. Turn off the power supply if an electrical component of the system requires service.
- 7. Perform any maintenance ONLY after completing these instructions.

See the **Compressed Natural Gas (CNG)** section of your Service Manual for additional maintenance information.

FUEL MANAGEMENT MODULE (FMM) REFERENCE DRAWING

Component drawing for Heil 151-4764 Fuel Management Module is shown below.



Figure 81. Fuel Management Module

CNG FUEL CYLINDER AND SYSTEM INSPECTION

If a CNG-fueled vehicle has been involved in an accident or fire, the system and cylinders must be inspected by a certified CNG fuel system inspector.

NOTICE

Inspections must be performed by qualified inspectors using guidelines from the fuel cylinder manufacturer in addition to the guidelines listed here.

- 1. Based on cylinder manufacturer recommendations and industry standard practices, visual CNG cylinder inspections should be performed at a frequency of 3 years or 36,000 miles, whichever occurs first.
- 2. In addition, Heil recommends a daily walk-around or pre-trip and post-trip visual inspection be performed.

DAILY CNrG[™] FUEL SYSTEM INSPECTION

Inspect the following items each day before vehicle operation:

- 1. Make sure all manual tank valves and the redhandled emergency shutoff valve on the FMM are in the OPEN position.
- 2. Check the high pressure gauge to make sure enough fuel is on-board and refuel if necessary.

- 3. Drain the low pressure filters located at engine per the engine manufacturers' recommendation.
- 4. Turn the ignition key to the on position, and watch the low pressure gauge. It should show about 125 psi.
- 5. Check the dashboard fuel gauge to make sure it is functioning.
- 6. Check the entire fuel system for any signs of damage or wear. Include checks for:
 - a. Gas leaks Smell for gas, look for frost or ice and listen for hissing noises at joints and components.
 - b. Pressure Relief Device (PRD) components Make sure all PRD vent line caps are in place.
 - c. Structural damage Housings, covers bent or damaged, fasteners missing or loose, check inside of tailgate for dents over 1/4" deep, or punctures.
- 7. If any system components or structural parts are damaged, perform a detailed inspection.

If everything checks out good, the vehicle is cleared for operation. If anything is wrong, a qualified CNG system technician should make the necessary repairs.

For instructions on how to perform a detailed CNrG fuel system inspection, see **Detailed CNrG Fuel System Inspection** in the Compressed Natural Gas (CNG) section of your Service Manual.

HEIL CNrG[™] SOLENOID SYSTEM OPTION

When equipped, the optional Heil CNrG Solenoid System will monitor and display live in-cab CNG system and tank pressures and notifications on the InSight[™] Diagnostic Display. Additionally, the system detects and alerts of leaks (visually and audibly) while closing solenoid valves of affected tanks to isolate the leak(s).

On the display, tanks are numbered starting with the tank at the top of the of the CNrG tailgate, "TANK-1", and ending with the tank lowest in the CNrG tailgate, in the system shown below, "TANK-7". When the system is operating without any issues, all boxes are green as shown below.



Figure 82. Main Display Screen

Summary of Features

- Display screen inside the cab which gives live pressure monitoring for each tank and system.
- Visual warning in form of messages and color on the screen along with audible alarm whenever solenoid failure occurs.
- System visual and audible warning if one of the pressure transducers is unplugged in either ignition ON or OFF conditions.
- Whenever the ignition is OFF and truck is not running, system gives audible alarm in the event of any leaks on tank or system side. The operator needs to turn the ignition ON and check the display screen that will show the tank location of the leak.
- As a safety feature, all solenoids will be closed whenever there is a leak. A maintenance bypass code will need to be entered to be able to open solenoids and drive the vehicle. The leak detection feature is available only when the ignition is OFF.
- Leaks are detected at a pressure difference of 600 psi.

HEIL CNrG[™] SOLENOID SYSTEM OPTION (CONTINUED)

Pressure Transducer Sensors

ALL Pressure Transducer Sensors MUST be functioning for System to be able to detect a leak.

A WARNING

Tank MUST be empty before removing tank Pressure Transducer Sensor.

Plugged directly into the live port of the valve of each tank and behind the FMM (Fuel Management Module) box live line, the pressure transducer sensors measure live pressures of each tank and of the system. When a pressure transducer sensor fails or becomes unplugged, the system sends a visual warning on the InSight[™] Diagnostic Display along with an audible alarm.

Whenever there is a single sensor issue, the main screen will show which sensor has failed as shown in the figure to the top right. However, if there are multiple sensor issues, it will tell you to go to alarm summary screen to get more details as shown in the figure to the bottom right.

NOTICE

The audible buzzer will be active regardless of ignition ON or ignition OFF and will not turn OFF until the issue is corrected.



Figure 83. Pressure Transducer Sensor behind FMM Unplugged/Faulty



Figure 84. Multiple Pressure Transducer Sensors Unplugged/Faulty

HEIL CNrG[™] SOLENOID SYSTEM OPTION (CONTINUED)

The Alarm Summary Screen can be reached by pressing the right arrow on the display twice.



Figure 85. Path to Alarm Summary Screen



igure 86. Alarm Summa Screen

Solenoid System Function

The valve body on each CNG tank has an integrated solenoid. The solenoids are normally closed when the ignition is OFF and open when ignition is ON and a voltage is supplied to them.

Leak Detection/Solenoid Lock

The system is capable of detecting a leak in the system or leak in any tank when the ignition is initially OFF and the leak starts. For safety purposes, if a leak is detected, all solenoids are locked in the closed position and not allowed to open until a maintenance code is entered and bypass is activated. The audible alarm activates whenever there is pressure difference detected of 600 psi or more and the truck ignition is OFF (ignition must be turned ON to see more details about the leak on the display screen).

NOTICE

Authorized Service Personnel should contact Heil Technical Service for the maintenance code to unlock the CNG solenoids.

HEIL CNrG[™] SOLENOID SYSTEM OPTION (CONTINUED)

Leak Detection/Solenoid Lock (Continued)

The figures on this page show example display screenshots of possible leak detection notifications. Other leak detection notifications exist and are not shown here.

You must follow all safety/emergency procedures of your company in the event of a CNG leak. At a minimum, follow the instructions on Emergency Shutdown Procedure section of this manual.



Figure 87. Tank 1 Leak. Maintenance Bypass Required.



Figure 88. Mutiple Tank Leaks. Maintenance Bypass Required.



Figure 89. System Leak. Maintenance Bypass Required.
DuraPack® Python®

HEIL CNrG[™] SOLENOID SYSTEM OPTION (CONTINUED)

Solenoid Failure Detection

The system is capable of detecting solenoid failures to open (in the event of a wiring or component issue) when the ignition is turned ON as per requirement of NFPA 52.

Whenever there is a single solenoid issue, the main screen will show which solenoid has failed as seen on the figure to the top right of this page. However, if there are multiple solenoid issues, it will tell you to go to alarm summary screen to get more details as seen in the figure to the bottom right. **Alarm Summary Screen** [17] can be reached by pressing the right arrow on the display twice.

The figures on this page show example display screenshots of solenoid failure detection notifications. Other solenoid failure detection notifications exist and are not shown here.

To defuel after a solenoid failure on one of the tanks, first refer to Heil CNrG[™] Solenoid System Defueling After Solenoid Failure Solenoid Failure described in CNG Fuel Module Defueling Methods 162.

NOTICE

The audible buzzer will be active only when ignition is ON and will not turn OFF until the issue is corrected.



Figure 90. Display Screenshot: Tank 2 Solenoid Failure



Figure 91. Display Screenshot: Multiple Solenoids Failed

Maintenance Bypass

The following are the steps must be followed by a qualified maintenance technician after getting any display messages described in this manual. This will allow a qualified service person to get the truck back on route/correct the issue:

- Driver will need to call maintenance department of their company in order to drive/move the truck since all solenoids are locked and need maintenance bypass for them to open.
- 2. For any leaking tank, open the oblong access covers on the street side of the CNrG tailgate and then close that tank's manual shut off valve. In case of system leak, solenoids will not open until the leak is stopped (system leak is a leak detected in the line going from FMM to tanks on high pressure side).
- 3. Go inside the cab and on display screen hold "ok" button on screen until it prompts you to enter maintenance code.
- 4. Enter the maintenance bypass code and you will see the screen shown in the figure to the right.

NOTICE

Authorized Service Personnel should contact Heil Technical Service for the maintenance bypass code to unlock the CNG solenoids.



Figure 92. Display Screenshot: Maintenance Screen

- 5. Make sure you have first closed the manual shut off valves on the tanks that are leaking (Step 2). You will notice that the Bypass Mode is OFF by default. Press "ok" button and turn ON Bypass Mode. Once you do this, all solenoids (except leaking tank/tanks) open. However, all tanks are now connected to each other and to the main supply/return line. This is the reason it is very important to first perform Step 2 before performing this step.
- 6. You will now be able to drive the truck to your maintenance department to evaluate and repair the leak. The audible alarm will not go OFF until the issue is corrected.

Low Fuel Level Detection

The system is capable of detecting low fuel levels and will give audible and visual alerts that the truck needs to be refueled, as shown in the figure below. Whenever pressure drops below 500 psi on the system side, the system will show a Low Fuel Warning alert message along with an audible alert.



Figure 93. Display Screenshot: Low Fuel Warning

CNG Tank Option Configuration

The system is designed for different tank configurations and is a common design which will work from 3 tank to 7 tank system. This helps the customer to upgrade to higher DGE (Diesel Gallon Equivalents) by adding more tanks without need to modify anything in this system. The figure below shows a snapshot of the Tank Option Configuration maintenance screen where you can configure the number of tanks on the truck.



Figure 94. Display Screenshot: Tank Option Configuration

System Inputs

The display screenshot shown below (within the maintenance mode menu) is used for troubleshooting and maintenance to gather information for the current status of the Ignition Power (ON or OFF) and the system voltage being supplied to the Cortex Controller[™]. It also provides the software revisions of the Cortex Display and Cortex Controller programs.



Figure 95. Display Screenshot: System Inputs

System Outputs

The display screenshot shown below (within the maintenance mode menu) is used for troubleshooting and maintenance to gather information for the current status of the Solenoids on each Tank (ON or OFF). It also provides the status of the System Alarm for the Cortex Controller.



Figure 96. Display Screenshot: System Outputs

Ignition Power OFF

The display notification shown in the figure below will only be displayed in the event that the InSight[™] Diagnostic Display has Ignition Power and the Cortex Controller[™] does not have Ignition Power. This Alarm can be beneficial in the event that all Tank Solenoids Valves have failed to open due to the loss of Ignition Power, which is required to open the Tank Solenoids Valves.



Figure 97. Display Screenshot: Ignition Power OFF

System Over Voltage

The display notification shown in the figure below will only be displayed in the event that the System Voltage is greater than 36 volts for 10 seconds, indicating that there is voltage too high to safely operate the Cortex Controller and Display.



Figure 98. Display Screenshot: System Over Voltage

System Under Voltage

The display notification shown in the figure below will only be displayed in the event that the System Voltage is less than 8 volts, indicating that there is voltage too low to safely operate the Cortex Controller and Display.



Figure 99. Display Screenshot: System Under Voltage

<u>Heil CNrG™ Solenoid System Defueling After</u> <u>Solenoid Failure</u>

Perform this procedure for any tank solenoid in the Heil CNrG[™] Solenoid System that has failed. This procedure is not needed for a system without solenoids. Refer to **Solenoid Failure Detection** 173 to help determine which solenoid has failed.

A. Preparation for Defueling

Follow the instructions below and then use one of the methods described in **CNG Fuel Module Defueling Methods Methods 162**. Ignition will have to be left ON to defuel all tanks with functioning solenoids.

- Remove the relevant side access cover to access the 1/4 turn valve of the tank on which the solenoid has failed. This valve is the long-handled valve located next to the manual shut-off valve.
- 2. Open the 1/4 turn valve for only the tank on which the solenoid has failed. Now, that tank will be connected to the main supply line and the gas will have a pathway to defuel even if the solenoid failed to open.
- 3. Now you can defuel by using one of the methods described in CNG Fuel Module Defueling Methods
- 4. Make sure that the display in the cab shows that all tanks and the system are completely depressurized before disconnecting any lines/fittings.

Α

accident 22 achieving payloads 110 after hydraulic filter change 128 AUTO 22 22.63.107 auto-lift auto-lift mode 107 auto-lift/manual lift mode 61 auto-pack mode 110 auto-pack/manual pack mode 61

B

battery disconnect switch 97 before operating the equipment 29 before starting a route 98 beware of overhead obstructions 29 22 bin body 16, 22 body lubrication guide 140.141 body preventive maintenance chart 136 body props 16 body raise (body hoist) cylinders 16

С

cab controls 16 care of decals 51 caution 22, 27 check the hydraulic oil level 99

Issued September 2017 Index clean and inspect the tailgate seal 122 clean behind the packer panel 118, 123 clean out hopper sump 118, 124 clean/inspect tailgate seal 117 CNG front of body decal placement 152 CNG fuel cylinder and system inspection 168 CNG system inspection/preventive care schedule 166 maintenenance 165.166 preparation before maintenance 166 CNG top of body decal placement 152 CNG vehicle operator emergency response 151 emergency response for gas leaks 150 vehicle fire procedures 150 CNrG tailgate decal images 154, 155, 156 CNrG tailgate decal placement 153 cold weather warmup procedure 98 collapsed position 22 compacting the load 110 compressed natural gas (CNG) fuel module 147.148. 149 Cortex Controller™ 16.22 customer care contact information 11 cycle all hydraulic functions 99

D

daily checklist 74, 97 daily checks and inspections 77 daily CNrG fuel system inspection 168 danger 22, 27

> Copyright 2017, Heil Environmental Printed in U.S.A.

decal images 42, 43, 44, 45, 46, 47, 48, 49, 50 decal placement dump/service hoist 34, 35, 36, 37 eject 38, 39, 40, 41 diagnostic fault codes 129 driving to pick-up locations 105

Ε

emergency shut down procedure 151 emergency venting/defueling procedure 151 emptying the body 116 end of day procedures 133 engine speed shutdown interlock 62 extend/EXTEND 22

F

factory body props 87, 88, 89, 90, 91, 92 factory tailgate props 93, 94 fault disabled functions 129 features 61 filter bypass shutdown interlock 62 filter bypass system 127 final inspection 133 fouling 22 22 front head fuel management module reference drawing 167 fueling procedure 157, 158, 159, 160 fully retracted position 22

G

grabber 22 GRIP 22

Η

harm 22 22 hazard Heil CNrG optional solenoid system leak detection 172 leak detection/solenoid lock 171 low fuel level detection 175 maintenance bypass 174 pressure transducer sensors 170 solenoid failure detection 171.173 solenoid system function 171 system inputs 176 system outputs 176 system over voltage 177 system under voltage 178 tank option configuration 175 Heil CNrG Solenoid System defueling after solenoid failure 178 Heil CNrG solenoid system option summary of features 169 Heil website 11 high transmission temperature interlock 62 hopper 16, 22 how to use this manual 5

hydraulic oil tank 16 hydraulic oil tank with sight gauge 100 hydraulic pump 16 hydraulic pump shutdown 127, 128

ignition keys 133 illuminate 22 important safety information 144, 145, 146 important safety precautions 28 in-cab alarm 66 66 in-cab buttons in-cab indicator lights 65.66.67 in-cab main control panel 65, 66, 67 in-cab switches 65, 66, 67 incident 22 informational decals 33 InSight[™] Diagnostic Display 61 InSight[™] diagnostic display notifications 127 interlock 22 in-transit position 101

L

LATCHED 22 leaving route for the landfill/transfer station 111 lift arm 16, 22 lift interlocks 62 lift lubrication guide 142 lift nomenclature 21 lifting and loading refuse with the Python lift arm 106. 107.108 loader latch 16 loader transit chain 16 LOCK 22 lock the tailgate 117, 123 locking out the unit 57 lock-out/tag-out 55.57 lower the tailgate 117 lower/LOWER 22 lowering the body 122

123

Μ

manual lift mode 108

lowering the tailgate

Ν

nomenclature 16 notice 22, 27

0

off/OFF 22 on/ON 22 operator 22 operator controls 16 operator proficiency 109 overhead clearances 29

Issued September 2017 Index

Copyright 2017, Heil Environmental Printed in U.S.A.

Ρ

packer 63 packer interlock 62 packer/eject panel & cylinders 16 packing near full load 110 packing on-the-move 110 parking the unit 133 parts central contact information 11 22 PN poperties of natural gas 149 precautionary statements 27 preparing the unit to check the hydraulic oil level 99 preparing to return to route 118, 124 pressure washer precautions 51 product nomenclature 15 prop the tailgate 117, 122 propping the body of a service hoist unit 87 propping the body of a service lift (serviceable eject) unit 90, 91, 92 propping the tailgate 93, 94 PTO 22 pump overspeed interlock 62 pump system 63 python lift joystick controls 68, 69, 70 python lift joystick decal 70

R

raise the tailgate 115, 119

raise/RAISE 22 raising the body 120, 121 reflective safety materials 33 remove refuse from the engine and exhaust areas 118, 124 reports to employer/supervisor 133 retract/RETRACT 22 RPM 22

S

safety decals 33 Select-O-Pack[™] 61, 63, 110 serial plate 14 serial plate location 13 service hoist 71 service hoist operation 87, 88, 89 service lift (serviceable eject) operation 90, 91, 92 setting up a dump unit for unloading 119 setting up an eject unit for unloading 115 should 22 side access door 22 side door interlock 62 starting vehicle 157 streetside vs. curbside 13

Т

tailgate 16 tailgate cylinders 16 tailgate latches 16

tailgate props 16 tech services contact information 11 to the mechanic 9 to the operator 7, 8 to the owner 6 top door (hopper cover) 22 transfer fueling (defueling) components 160, 161, 162, 163, 164 modes 160, 161, 162, 163, 164 procedures 160, 161, 162, 163, 164 traveling position 101

U

unit 22 unit interlocks 62 UNLATCHED 22 unloading 29 unloading a dump unit 120, 121, 122, 123, 124 unloading an eject unit 116, 117, 118 UNLOCK 22 use of curb side drive 105 use of curbside drive 101, 111 use personal protective equipment 29

W

warming up the hydraulic oil 98
warning 22, 27
warning signals 64
warranty claims and inquiries 10

Issued September 2017 Index washout system 133
Waste Management specific interlocks 64
Waste Management specific warning signals 64
when working in or around the vehicle 29

DuraPack® Python®

NOTES:



HEIL ENVIRONMENTAL WARRANTY STATEMENT

The Heil Co. d/b/a Heil Environmental ("Heil") warrants its solid waste collection equipment to be free from defects in material and workmanship under normal use for a period of one (1) year or 2000 hours of operation (whichever comes first) from the date of equipment In-Service or during the period of coverage offered by an extended warranty program, when proper service and maintenance as described in Heil Service Bulletins and Parts & Service Manuals are performed. The standard or extended equipment warranty is not transferable except for sales demonstration units.

This warranty is expressly limited to the repair or replacement of any component or part thereof, of any such refuse or recycling collection body manufactured by Heil that is proven to Heil's satisfaction to have been defective in material or workmanship. Such components or parts shall be repaired or replaced at Heil's option without cost to the standard purchaser for parts and labor provided such unit is returned to an authorized Heil Distributor for replacement or repair. The repair or replacement must be made during the standard or extended warranty coverage period. Before any warranty can be allowed on new equipment, a validated warranty registration form must be on file with Heil's Customer Service Department within sixty (60) days of the equipment's In-Service date. Wear items are excluded from warranty coverage.

All OEM service parts sold by Heil have a six (6) month warranty from the date of purchase. Aftermarket parts purchased from Heil are supported by a 90-day warranty. The parts warranty covers parts only, providing that factory inspection reveals a defect in material or workmanship. Labor, troubleshooting, equipment downtime, etc. is not covered under the parts warranty policy.

HEIL MAKES NO OTHER WARRANTY, EXPRESSED OR IMPLIED, AND MAKES NO WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR ANY PARTICULAR PURPOSE. HEIL DOES NOT ASSUME ANY LIABILITY OR ACCEPT CLAIMS FOR LOSS OF PROFITS, PRODUCT DOWN TIME OR ANY OTHER DIRECT, INCIDENTAL OR INDIRECT CONSEQUENTIAL LOSSES, COSTS, DAMAGES OR DELAYS.

Any improper use, operation beyond rated equipment or component capacity, substitution of parts that are not Heil-approved, or any alteration or repair by others in such a manner as in Heil's sole judgment affect the product operation or integrity shall void the warranty.

Other than the extension of the standard warranty period purchased under a supplemental Heil Extended Warranty Program, no employee or representative is authorized to modify this warranty in any way nor shall any other warranties be granted. No dealer-supplied warranty program is endorsed or supported by Heil.

Heil retains the right to modify its factory warranty program prospectively at any time.



www.heil.com

Customer Care: 866-ASK-HEIL (866-275-4345)

Heil Environmental 4301 Gault Avenue North Fort Payne, AL 35967-9984

Parts Central: 800-528-5308

Technical Service: 866-310-4345 TechSupport@DoverESG.com